



**1297-M012-0\_R**

**G3.128R  
GP3.128R**

INSTRUCTION MANUAL

**GB**

TRANSLATION FROM THE  
ORIGINAL INSTRUCTIONS

---

*For spare parts drawings refer to the section "LIST OF COMPONENTS" enclosed to this manual.*

---

- For any further information please contact your local dealer or call:

Technical services: **RAVAGLIOLI S.p.A.** - Via 1° Maggio, 3 - 40037 Pontecchio Marconi - Bologna Italy  
Phone (+39) 051 6781511 - Telex 510697 RAV I - Fax (+39) 051 846349 - e-mail: [aftersales@ravaglioli.com](mailto:aftersales@ravaglioli.com)

**1297-M012-0\_R - Rev. n. 0 (09/2014)**



## SUMMARY


<b>SYMBOLS USED IN THE MANUAL AND ON THE MACHINE</b>	<b>5</b>	<b>14.1 Switching the machine on and off</b>	<b>22</b>
<b>1.0 GENERAL INTRODUCTION</b>	<b>7</b>	<b>14.2 Balancing programs setting</b>	<b>23</b>
1.1 Introduction	7	14.2.1 Programs rapid setting and measurements through distance-diameter caliper arm	23
<b>2.0 INTENDED USE</b>	<b>7</b>	14.2.2 Programs setting through "Measurement being acquired" screen page	26
2.1 Staff training	7	<b>14.3 Indicative display of points where to detect measures/to fit weight</b>	<b>27</b>
<b>3.0 SAFETY DEVICES</b>	<b>8</b>	14.3.1 Weights positioning	27
3.1 Residual risks	8	<b>14.4 Displaying the active/modifiable field</b>	<b>27</b>
<b>4.0 GENERAL SAFETY RULES</b>	<b>8</b>	<b>14.5 Wheel balancing screen page description</b>	<b>28</b>
<b>5.0 PACKING AND MOBILIZATION FOR TRANSPORT</b>	<b>9</b>	14.5.1 Balancing mode	29
<b>6.0 UNPACKING</b>	<b>10</b>	<b>14.6 Use of machines with disabled automatic gauge</b>	<b>31</b>
<b>7.0 MOBILIZATION</b>	<b>10</b>	14.6.1 Manual setting of wheel dimensions	31
<b>8.0 WORKING ENVIRONMENT CONDITIONS</b>	<b>10</b>	<b>14.7 Standard balancing programs</b>	<b>31</b>
8.1 Working area	11	14.7.1 Static	31
8.2 Lighting	11	14.7.2 Static-1	32
<b>9.0 MACHINE ASSEMBLY</b>	<b>11</b>	14.7.3 Static-2	32
9.1 Anchoring system	11	14.7.4 Dynamic	32
9.2 Fixtures contained in the packing	12	14.7.5 ALU-S	32
9.3 Assembly procedures	13	14.7.6 ALU-S1	33
9.3.1 Fitting the mandrel on the flange	13	14.7.7 ALU-S2	33
9.3.2 Fitting and removal of the pneumatic mandrel on the flange	13	14.7.8 ALU-1	33
9.3.3 Fitting of external data gauge (optional)	15	14.7.9 ALU-2	33
9.3.4 Fitting of professional external data gauge (optional)	16	14.7.10 ALU-3	34
9.3.5 Monitor fitting	16	14.7.11 ALU-4	34
9.3.6 Fitting the wheel cover	17	<b>14.8 Optional balancing programs</b>	<b>34</b>
<b>10.0 ELECTRICAL CONNECTION</b>	<b>17</b>	14.8.1 ECO-WEIGHT mode	34
10.1 Electrical checks	18	14.8.2 SPLIT mode	36
<b>11.0 AIR CONNECTIONS</b>	<b>18</b>	14.8.3 Weights hidden behind spokes mode	38
<b>12.0 FITTING THE WHEEL ON THE MANDREL</b>	<b>19</b>	14.8.4 Matching mode	39
12.1 Fitting of the wheel (only for G3.128R model)	19	<b>14.9 Special balancing programs</b>	<b>42</b>
12.2 Fitting of the wheel (only for GP3.128R model)	20	14.9.1 Pax	42
<b>13.0 CONTROL PANEL</b>	<b>22</b>	<b>14.10 Recalculation Function</b>	<b>42</b>
<b>14.0 WHEEL BALANCING</b>	<b>22</b>	<b>14.11 Motorbike Mode wheel balancing</b>	<b>43</b>
		<b>15.0 USER MENU (OPTIONS AND CALIBRATION)</b>	<b>44</b>
		15.1 Options menu	44
		15.1.1 Lower weight limit	46
		15.1.2 Setting adhesive weight dimensions and static threshold percentage	46
		15.1.3 User management	47
		15.2 Machine calibration	48
		15.2.1 Mandrel "Ø" calibration	48



15.2.2 Weight measurement sensors calibration _____	49
15.2.3 Gauge calibration _____	50
15.2.4 Touch monitor calibration _____	53
<b>16.0 ERROR SIGNALS _____</b>	<b>54</b>
<b>17.0 ROUTINE MAINTENANCE _____</b>	<b>55</b>
<b>18.0 TECHNICAL DATA _____</b>	<b>56</b>
18.1 Dimensions _____	57
<b>19.0 STORING _____</b>	<b>58</b>
<b>20.0 SCRAPPING _____</b>	<b>58</b>

20.1 Instructions for the correct management of waste from electric and electronic equipment (WEEE) according to the Italian legislative decree 49/14 _____	58
<b>21.0 REGISTRATION PLATE DATA _____</b>	<b>58</b>
<b>22.0 FUNCTIONAL DIAGRAMS _____</b>	<b>58</b>
Table A - Electrical and pneumatic connection diagram _____	59
<b>23.0 LIST OF COMPONENTS</b>	

**Fig. 1 - G3.128R - GP3.128R**















**KEY**

- 1 - Weight holding bridge
- 2 - Pneumatic mandrel (only for GP3.128R model)
- 3 - Distance-diameter caliper
- 4 - Threaded mandrel (only for G3.128R model)
- 5 - Protection guard
- 6 - Foot brake (only for G3.128R model / pneumatic mandrel open-close pedal (only for GP3.128R model)
- 7 - Main switch
- 8 - External data gauge (optional)
- 9 - Push-button panel with 7 keys
- 10 - Monitor with touch control panel (supplemented)
- 11 - Pusher ring
- 12 - Rapid ring nut (only for G3.128R model)
- 13 - Locking sleeve (only for GP3.128R model)
- 14 - Cones
- 15 - Professional external data gauge (optional)
- 16 - Grippers for weight fitting
- 17 - Fixed laser unit + led light (optional)




## SYMBOLS USED IN THE MANUAL AND ON THE MACHINE

Symbols	Description
	Read instruction manual.
	FORBIDDEN!
 2167000	Wear work gloves.
	Wear work shoes.
 2167000	Wear safety goggles.
	Wear safety earcaps.
 99990758	Shock hazard.
	Caution: hanging loads.
	Warning. Be particularly careful (possible material damages).

Symbols	Description
	Mandatory. Operations or jobs to be performed compulsorily.
	Danger! Be particularly careful.
	Move with fork lift truck or pallet truck.
	Lift from above.
 1541000	General danger.
	Technical assistance necessary. Do not perform any intervention.
	Note. Indication and/or useful information.
 999912940	Attention: never lift the machine by means of the mandrel.
 99990114	Arrow plate.

**INFORMATION PLATE LOCATION TABLE**



**Code numbers of plates**

<b>99990114</b>	<i>Arrow plate</i>
<b>99990758</b>	<i>Electricity danger plate</i>
<b>999910050</b>	<i>Protection device use plate</i>
<b>999912940</b>	<i>Lifting plate</i>
<b>999914160</b>	<i>Voltage 230V 50/60 Hz 1 Ph plate</i>
<b>999914170</b>	<i>Voltage 115V 50/60 Hz 1 Ph plate</i>
<b>999916310</b>	<i>Skip label</i>
<b>999920190</b>	<i>New G3 logo plate</i>
<b>999920540</b>	<i>Laser point danger plate</i>
•	<i>Serial number plate</i>
*	<i>Manufacturer trademark nameplate</i>



**IF ONE OR MORE PLATES DISAPPEARS FROM THE MACHINE OR BECOMES DIFFICULT TO READ, IT MUST BE REPLACED. QUOTE THE CODE NUMBER WHEN REORDERING.**



**NOTE: SOME OF THE PICTURES PRESENT IN THIS MANUAL HAVE BEEN OBTAINED FROM PICTURES OF PROTOTYPES, THEREFORE THE STANDARD PRODUCTION ACCESSORIES CAN BE DIFFERENT IN SOME COMPONENTS.**

## 1.0 GENERAL INTRODUCTION

**This manual is an integral part of the product and must be retained for the whole operating life of the machine.**

Carefully study the warnings and instructions contained in this manual. It contains important instructions regarding **FUNCTIONING, SAFE USE and MAINTENANCE.**



**KEEP THE MANUAL IN A KNOWN, EASILY ACCESSIBLE PLACE FOR ALL ACCESSORY OPERATORS TO CONSULT IT WHENEVER IN DOUBT.**



**THE MANUFACTURER DISCLAIMS ALL RESPONSIBILITY FOR ANY DAMAGE OCCURRED WHEN THE INDICATIONS GIVEN IN THIS MANUAL ARE NOT RESPECTED: AS A MATTER OF FACT, THE NON-COMPLIANCE WITH SUCH INDICATIONS MIGHT LEAD TO EVEN SERIOUS DANGERS.**

### 1.1 Introduction

Thank you for preferring this wheel balancer. We feel sure you will not regret your decision.

This machine has been designed for use in professional workshops and stands out for its reliability and easy, safe and rapid operation. With just a small degree of maintenance and care, this wheel balancer will give you many years of trouble-free service and lots of satisfaction.

## 2.0 INTENDED USE

The models **G3.128R - GP3.128RMACHINES**, and relative versions, are wheels balancing machines for car and light transport, projected to be used exclusively to cancel out, or at least reduce to acceptable limits the vibrations of the wheels, by fitting counterweights of suitable size and in specific positions to the same wheels that are not correctly balanced.



**DANGER: THIS MACHINE MUST BE USED STRICTLY FOR THE INTENDED PURPOSE IT WAS DESIGNED FOR (AS INDICATED IN THIS MANUAL).**



**THE MANUFACTURER CANNOT BE HELD RESPONSIBLE FOR ANY DAMAGE CAUSED BY IMPROPER, ERRONEOUS, OR UNACCEPTABLE USE.**



**AN INTENSIVE USE OF THE EQUIPMENT IN INDUSTRIAL ENVIRONMENT IS NOT RECOMMENDED.**

### 2.1 Staff training

**The machine may be operated only by suitably trained and authorized personnel.**

Given the complexity of the operations necessary to manage the machine and to carry out the operations safely and efficiently, the personnel must be trained in such a way that they learn all the information necessary to operate the machine as intended by the manufacturer.



**A CAREFUL READING OF THIS INSTRUCTION MANUAL FOR USE AND MAINTENANCE AND A SHORT PERIOD OF TRAINING WITH SKILLED PERSONNEL CAN BE AN ENOUGH PREVENTIVE PREPARATION.**

### 3.0 SAFETY DEVICES


- **Master switch positioned on the rear of the machine**

Its function is to disconnect machine electric supply.

- **Protection guard**

Its function is to protect the operator from possible projections of materials on the wheel during its spin. Wheel spinning is normally prevented if the wheel protection guard is raised (open). When the protection guard is open, this interrupts the circuit that triggers the motor and automatic start is prevented, including in the case of an error.



Press  stop key to stop wheel rotation in emergency conditions.

#### **3.1 Residual risks**

The machine was subjected to a complete analysis of risks according to reference standard EN ISO 12100. Risks are as reduced as possible in relation with technology and product functionality.

Possible residual risks have been emphasized through pictorial representations and warnings which placing is indicated in " PLATE POSITIONING TABLE" at page 6.

### 4.0 GENERAL SAFETY RULES



- Any tampering with or modification to the machine not previously authorized by the manufacturer exempts the latter from all responsibility for damage caused by or derived from said actions.
- Removing of or tampering with the safety devices or with the warning signals placed on the machine leads to serious dangers and represents a transgression of European safety rules.
- Use of the machine is only permitted in places free from **explosion** or **fire** hazard and in **dry places under cover**.
- Original spare parts and accessories should be used.



**THE MANUFACTURER CANNOT BE HELD RESPONSIBLE FOR ANY DAMAGE CAUSED BY IMPROPER, ERRONEOUS, OR UNACCEPTABLE USE.**

- Installation must be conducted only by qualified personnel exactly according to the instructions that are given below.
- Ensure that there are no dangerous situations during the machine operating manoeuvres. Immediately stop the machine if it miss-functions and contact the assistance service of an authorized dealer.
- In emergency situations and before carrying out any maintenance or repairs, disconnect all supplies to the machine by using the main switch, placed on the machine itself, and unplugging the power supply.
- The machine electrical supply system must be equipped with an appropriate earthing, to which the yellow-green machine protection wire must be connected.
- Ensure that the work area around the machine is free of potentially dangerous objects and that there is no oil since this could damage the tyre. Oil on the floor is also a potential danger for the operator.
- **UNDER NO CIRCUMSTANCES** must the machine be used to spin anything but vehicle wheels. Bad locking can cause rotating parts to come loose, with potential damage to the machine and anything in the vicinity and injury to the operator.





**OPERATORS MUST WEAR SUITABLE WORK CLOTHES, PROTECTIVE GLASSES AND GLOVES, AGAINST THE DANGER FROM THE SPRAYING OF DANGEROUS DUST, AND POSSIBLY LOWER BACK SUPPORTS FOR THE LIFTING OF HEAVY PARTS. DANGLING OBJECTS LIKE BRACELETS MUST NOT BE WORN, AND LONG HAIR MUST BE TIED UP. FOOTWEAR SHOULD BE ADEQUATE FOR THE TYPE OF OPERATIONS TO BE CARRIED OUT.**



- The machine handles and operating grips must be kept clean and free from oil.
- The workshop must be kept clean and dry. Make sure that the working premises are properly lit. The machine can be operated by a single operator. Unauthorized personnel must remain outside the working area, as shown in **Fig. 3**. Avoid any hazardous situations. Do not use air-operated or electrical equipment when the shop is damp or the floor slippery and do not expose such tools to atmospheric agents.
- When operating and servicing this machine, carefully follow all applicable safety and accident-prevention precautions. The machine must not be operated by professionally unskilled persons.



**WHEN USING THE MODELS WITH WHEEL PNEUMATIC CLAMPING, DURING MANDREL OPENING/CLOSING OPERATIONS, BE EXTREMELY CAREFUL AND KEEP YOUR HANDS OR OTHER PARTS OF YOUR BODY AWAY FROM THE MOVING MANDREL.**

## 5.0 PACKING AND MOBILIZATION FOR TRANSPORT




**HAVE THE MACHINE HANDLED BY SKILLED PERSONNEL ONLY.**

**THE LIFTING EQUIPMENT MUST WITHSTAND A MINIMUM RATED LOAD EQUAL TO THE WEIGHT OF THE PACKED MACHINE (SEE PARAGRAPH TECHNICAL SPECIFICATIONS).**


The machine is packed completely assembled. The machine is inside a carton box which size is mm 1040x950x1090.

Movement must be by pallet-lift or fork-lift trolley. The fork lifting points are indicated on the packing.

**Fig. 2**



## 6.0 UNPACKING




The cardboard box is supported with plastic strapping. Cut the strapping with suitable scissors. Use a small knife to cut along the lateral axis of the box and open it like a fan.



It is also possible to unnailed the cardboard box from the pallet it is fixed to. After removing the packing, and in the case of the machine packed fully assembled, check that the machine is complete and that there is no visible damage.

If in doubt **do not use the machine** and refer to professionally qualified personnel (to the seller).

The packing (plastic bags, expanded polystyrene, nails, screws, timber, etc.) should not be left within reach of children since it is potentially dangerous. These materials should be deposited in the relevant collection points if they are pollutants or non biodegradable.



## 7.0 MOBILIZATION



If the machine has to be moved from its normal work post, the movement must be conducted following the instructions listed below.

- Protect the exposed corners with suitable material (Pluribol/cardboard).
- Do not use metallic cables for lifting.
- Make sure the electrical and pneumatic supply (for GP3.128R model) of the machine is not connected.
- Place again the machine onto the original pallet with whom it was delivered.
- Use transpallet or fork-lift for handling.

## 8.0 WORKING ENVIRONMENT CONDITIONS


The machine must be operated under proper conditions as follows:

- temperature: 0° + 45° C
- relative humidity: 30 - 90% (dew-free)
- atmospheric pressure: 860 - 1060 hPa (mbar).

The use of the machine in ambient conditions other than those specified above is only allowed after prior agreement with and approval of the manufacturer.

## 8.1 Working area

Fig. 3



The location of the machine requires a usable space as indicated in **Fig. 3**. The positioning of the machine must be according to the distances shown. From the control position the operator is able to observe all the machine and surrounding area. He must prevent unauthorized personnel or objects that could be dangerous from entering the area.

The machine must be fixed on a flat floor surface, preferably of cement or tiled. Avoid yielding or irregular surfaces.

The base floor must be able to support the loads transmitted during operation.

This surface must have a strength of at least 500 kg/m<sup>2</sup>. The depth of the solid floor must be sufficient to guarantee that the anchoring bolts hold.

## 8.2 Lighting

The machine does not require its own lighting for normal working operations. However, it must be used in an adequately lit environment.

In case of poor lighting use lamps having total power 800/1200 Watt.



**IF IT IS INSTALLED, EACH TIME THE ROD OF THE GAUGE IS EXTRACTED FROM ITS HOUSING, THE LED LIGHT (FIG. 1 REF. 17) TURNS ON MAKING THE INSIDE OF THE WHEEL WHERE THE OPERATOR MUST WORK BRIGHTER.**

## 9.0 MACHINE ASSEMBLY

After having freed the various components from the packing check that they are complete, and that there are no anomalies, then comply with the following instructions for the assembly of the components making use of the attached series of illustrations.

### 9.1 Anchoring system

The packed machine is fixed to a pallet by support feet. Such feet also fix the machine to the ground through anchor small blocks as shown in **Fig. 4 ref. 1**.



**IN CASE OF WHEEL WEIGHING MORE THAN 30 KG, IT IS COMPULSORY TO FIX TO THE GROUND BY MEANS OF SCREW ANCHORS.**




Fig. 4

The holes in the solid floor must be about 10 cm deep with a diameter of 8 MA.

The bolts (**Fig. 4 ref. 1**) must be inserted in the pre-arranged holes and fully tightened (tightening torque: about 22 Nm) until reaching the system full seal.

## **9.2 Fixtures contained in the packing**

The packing case contains also the fixtures box. Check that all the parts listed below are there (see **Fig. 5**).


For **G3.128R** model

<b>Code</b>	<b>Description</b>	<b>N.</b>
<b>GAR101</b>	<i>Rapid ring nut + pusher ring</i>	<b>1</b>
<b>GAR111</b>	<i>Cones + protection cup</i>	<b>1</b>
<b>129571492</b>	<i>Gauge</i>	<b>1</b>
<b>1300A004</b>	<i>Weight pliers</i>	<b>1</b>
<b>999072</b>	<i>Carriages counterweight</i>	<b>1</b>

For **GP3.128R** model

<b>Code</b>	<b>Description</b>	<b>N.</b>
<b>GAR108</b>	<i>Rapid ring nut + pusher ring</i>	<b>1</b>
<b>GAR111</b>	<i>Cones + protection cup</i>	<b>1</b>
<b>129571492</b>	<i>Gauge</i>	<b>1</b>
<b>1300A004</b>	<i>Weight pliers</i>	<b>1</b>
<b>999072</b>	<i>Carriages counterweight</i>	<b>1</b>

**Fig. 5**



### 9.3 Assembly procedures

#### 9.3.1 Fitting the mandrel on the flange

Only for G3.128R model

Screw the mandrel with an Allen wrench (Fig. 6 ref. 1) on the flange (Fig. 6 ref. 2).




Fig. 6

#### 9.3.2 Fitting and removal of the pneumatic mandrel on the flange

Only for GP3.128R model

##### FITTING

1. After making power and air connections switch on the machine (the pneumatic mandrel always opens when the machine is switched on). Switch the machine off. Fit the internal mandrel on the flange and tighten it with the wrench provided (Fig. 7 and Fig. 8).




Fig. 7




Fig. 8

2. Press the brake's pedal and, at the same time, tighten the internal mandrel as far as it will go using the wrench provided (**Fig. 9**).




Fig. 9

3. Fit the external mandrel and tighten it manually (**Fig. 10**).




Fig. 10

4. Close the pneumatic mandrel by means of the pedal to access the key socket (**Fig. 11**).




Fig. 11

5. Press the brake pedal and at the same time block the external mandrel using the wrench supplied (**Fig. 12**).




Fig. 12

#### **REMOVAL**


- Close the pneumatic mandrel by means of the pedal to access the key socket (**Fig. 11**).
- Press the brake pedal and at the same time release the external mandrel by using the wrench provided (**Fig. 12**).
- Remove the external mandrel, open the pneumatic mandrel by means of the pedal provided and loosen the internal mandrel using the special wrench (**Fig. 9**).

### 9.3.3 Fitting of external data gauge (optional)

1. Unscrew the fastening screws of the equalizer's support (**Fig. 13 ref. 1**), being very careful about holding the same support.
2. Unscrew the 3 screws (**Fig. 13 ref. 2**) to the gauge bracket (**Fig. 13 ref. 3**) and in the special inserts placed on the rear side of the frame. Lock the gauge arm (**Fig. 13 ref. 4**) by screwing the 2 screws provided (**Fig. 13 ref. 5**). Lock these screws with the nuts (**Fig. 13 ref. 6**) so that the mandrel and the gauge arm are levelled out (see **Fig. 14**).

4. Connect connector (**Fig. 15 ref. 1**) of the cable coming from inside the machine to connector (**Fig. 15 ref. 2**) of the cable coming from the gauge arm. Fit the section of the cable with the connectors inside the arm (**Fig. 15 ref. 3**).
5. Fasten the cable with clamps.
6. Enable the external data gauge and carry out the device's calibration.

Fig. 13



3. Also make sure the gauge tip (**Fig. 14 ref. 1**) is positioned at the centre of the mandrel.

Fig. 14






Fig. 15


### **9.3.4 Fitting of professional external data gauge (optional)**

1. Unscrew the fastening screws of the equalizer's support (**Fig. 16 ref. 1**), being very careful about holding the same support.
2. Unscrew the 3 screws (**Fig. 16 ref. 2**) to the gauge bracket (**Fig. 16 ref. 3**) and in the special inserts placed on the rear side of the frame. Lock the gauge arm (**Fig. 16 ref. 4**) by screwing the 2 screws provided (**Fig. 16 ref. 5**). Lock these screws with the nuts (**Fig. 16 ref. 6**) so that the mandrel and the gauge arm are levelled out (see **Fig. 17**).



**Fig. 16**


3. Also make sure the gauge tip (**Fig. 17 ref. 1**) is positioned at the centre of the mandrel.



**Fig. 17**

4. Connect connector (**Fig. 18 ref. 1**) of the cable coming from inside the machine to connector (**Fig. 18 ref. 2**) of the cable coming from the gauge arm. Fit the section of the cable with the connectors inside the arm (**Fig. 18 ref. 3**).


5. Fasten the cable with clamps.
6. Enable the external data gauge and carry out the device's calibration.



**Fig. 18**

### **9.3.5 Monitor fitting**

1. Unscrew the nuts (**Fig. 19 ref. 2**), remove the washers (**Fig. 19 ref. 3**) and turn the support complete with monitor (**Fig. 19 ref. 1**) of 90°. Fix the support complete with monitor to the machine laying the washers (**Fig. 19 ref. 3**) and screwing the nuts (**Fig. 19 ref. 2**) previously unscrewed.



**Fig. 19**





**DURING THIS OPERATION PAY PARTICULAR ATTENTION TO THE POWER SUPPLY CABLE/SIGNAL OF THE MONITOR IN ORDER NOT TO DAMAGE IT.**


### 9.3.6 Fitting the wheel cover

1. Mount the protection guard (**Fig. 20 ref. 1**) to the support (**Fig. 20 ref. 2**) using the screws (**Fig. 20 ref. 3**), interposing the Belleville washers (**Fig. 20 ref. 4**).
2. Tighten the screws (**Fig. 20 ref. 3**) in order to make the guard (**Fig. 20 ref. 1**) lift or lower without bumping against the limit switch. Carry out the adjustment so that it's possible to manually guide the guard both during closing and opening.



**DURING GUARD'S ASSEMBLY, PAY ATTENTION TO THE MICRO PLACED INSIDE THE MACHINE.**

Fig. 20



## 10.0 ELECTRICAL CONNECTION



**EVEN THE TINIEST PROCEDURE OF AN ELECTRICAL NATURE MUST BE CARRIED OUT BY PROFESSIONALLY QUALIFIED STAFF.**



**BEFORE CONNECTING THE MACHINE MAKE SURE THAT:**

- THE MAIN POWER RATING CORRESPONDS TO THE MACHINE RATING AS SHOWN ON THE MACHINE PLATE;
- ALL MAIN POWER COMPONENTS ARE IN GOOD CONDITION;
- THE ELECTRICAL SYSTEM IS PROPERLY GROUNDED (GROUND WIRE MUST BE THE SAME CROSS-SECTION AREA AS THE LARGEST POWER SUPPLY CABLES OR GREATER);
- MAKE SURE THAT THE ELECTRICAL SYSTEM FEATURES A CUTOUT WITH DIFFERENTIAL PROTECTION SET AT 30 mA.

Connect the machine up to the mains by means of the 3-pole plug provided (230 V single-phase) through the wall socket.

If the plug provided is not suitable for the wall socket, fit a plug that complies with local and applicable regulations. This operation must be performed by expert and professional personnel.



**FIT A TYPE-APPROVED (AS REPORTED BEFORE) PLUG TO THE MACHINE CABLE (THE GROUND WIRE IS YELLOW/GREEN AND MUST NEVER BE CONNECTED TO THE PHASE LEADS). MAKE SURE THAT THE ELECTRICAL SYSTEM IS COMPATIBLE WITH THE RATED POWER ABSORPTION SPECIFIED IN THIS MANUAL AND APT TO ENSURE THAT VOLTAGE DROP UNDER FULL LOAD WILL NOT EXCEED 4% OF RATED VOLTAGE (10% UPON START-UP).**



**FAILURE TO OBSERVE THE ABOVE INSTRUCTIONS WILL IMMEDIATELY INVALIDATE THE WARRANTY.**

### **10.1 Electrical checks**




**BEFORE STARTING UP THE WHEEL-BALANCER, BE SURE TO BECOME FAMILIAR WITH THE LOCATION AND OPERATION OF ALL CONTROLS AND CHECK THEIR PROPER OPERATION (SEE PAR. "CONTROLS").**



**CARRY OUT A DAILY CHECK OF MAINTAINED-TYPE CONTROLS CORRECT FUNCTIONING, BEFORE STARTING MACHINE OPERATION.**

Once the plug/socket connection has been made, turn on the machine using the master switch (**Fig. 21 ref. 1**).



**Fig. 21**

## **11.0 AIR CONNECTIONS**


**Only for GP3.128R model**



**IN CASE OF A CHANCE SUPPLY FAILURE, AND/OR BEFORE ANY PNEUMATIC CONNECTIONS, MOVE THE CONTROLS TO THE NEUTRAL POSITION.**

Connect the wheel balancer to the centralised compressed-air system by means of the connection on the back of the machine (see **Fig. 22**).

The air system supplying the machine must be able to supply filtered and de-humidified air at a pressure between 8 and 10 bar. It must feature an on-off valve upstream of the machine.



**Fig. 22**

## 12.0 FITTING THE WHEEL ON THE MANDREL



To achieve perfect balancing, the wheel must be carefully and properly fitted on the mandrel. Imperfect centring will inevitably cause unbalances.



**MOST IMPORTANT IS THAT ORIGINAL CONES AND ACCESSORIES ARE USED MADE SPECIFICALLY FOR USE ON THE WHEEL BALANCER.**

Wheel fitting using the cones provided is illustrated below. For alternative fittings, using optional accessories, refer to the special instructions provided separately.

### 12.1 Fitting of the wheel (only for G3.128R model)

1. Remove any type of foreign body from the wheel (**Fig. 23 ref. 3**): pre-existing weights, stones and mud, and make sure the mandrel (**Fig. 23 ref. 1**) and the rim centring area are clean before fitting the wheel on the mandrel.
2. Carefully choose the cone (**Fig. 23 ref. 2**) most suitable for the wheel to be balanced. These accessories must be selected according to the shape of the rim. Position the wheel (**Fig. 23 ref. 3**), fitting the cone (**Fig. 23 ref. 2**) on the mandrel (**Fig. 23 ref. 1**): be careful (otherwise this could seize) until this rests against the support flange (**Fig. 23 ref. 4**).
3. Fit the wheel with the inner side of the rim towards the wheel balancer and against the cone.




Fig. 23

4. Fit the protection cap (**Fig. 24 ref. 1**) in the locknut (**Fig. 24 ref. 2**) and fasten against the wheel.




Fig. 24

Some aluminium wheels, with very high centring, must be fitted with the cone outside the wheel.

5. Clean the mandrel (**Fig. 25 ref. 1**) before fitting the wheel.
6. Fit the wheel (**Fig. 25 ref. 3**) with the inside of the rim towards the wheel balancer, until the wheel is up against the support flange (**Fig. 25 ref. 2**).





Fig. 25


7. Fit the cone (**Fig. 26 ref. 3**) with the narrowest part turned towards the wheel
8. Fit the grip-ring (**Fig. 26 ref. 1**) in the nut (**Fig. 26 ref. 2**) and fasten the cone (**Fig. 26 ref. 3**).



## **12.2 Fitting of the wheel (only for GP3.128R model)**



Open the pneumatic mandrel by means of the special pedal, see **Fig. 27**.



1. Remove any type of foreign body from the wheel (**Fig. 28 ref. 3**): pre-existing weights, stones and mud, and make sure the mandrel (**Fig. 28 ref. 1**) and the rim centring area are clean before fitting the wheel on the mandrel.
2. Carefully choose the cone (**Fig. 28 ref. 2**) most suitable for the wheel to be balanced. These accessories must be selected according to the shape of the rim. Position the wheel (**Fig. 28 ref. 3**), fitting the cone (**Fig. 28 ref. 2**) on the mandrel (**Fig. 28 ref. 1**): be careful (otherwise this could seize) until this rests against the support flange (**Fig. 28 ref. 4**).
3. Fit the wheel with the inner side of the rim towards the wheel balancer and against the cone.




Fig. 28

4. Fit the protection cap (**Fig. 29 ref. 1**) in the bush (**Fig. 29 ref. 2**) and bring everything against the wheel.




Fig. 29

Lift the control pedal to close the mandrel and then clamp the wheel.

Some aluminium wheels, with very high centring, must be fitted with the cone outside the wheel.

5. Clean the mandrel (**Fig. 30 ref. 1**) before fitting the wheel.
6. Fit the wheel (**Fig. 30 ref. 3**) with the inside of the rim towards the wheel balancer, until the wheel is up against the support flange (**Fig. 30 ref. 2**).




Fig. 30

7. Fit the cone (**Fig. 31 ref. 3**) with the narrowest part turned towards the wheel

8. Fit the grip-ring (**Fig. 31 ref. 1**) in the bush (**Fig. 31 ref. 2**) and bring everything against the wheel.




Fig. 31

Close the pneumatic mandrel by lifting the appropriate control pedal.




**DURING MANDREL OPENING/  
CLOSING OPERATIONS, BE CAREFUL  
TO KEEP YOUR HANDS AND  
OTHER PARTS OF THE BODY  
AWAY FROM THE MANDREL.**

### 13.0 CONTROL PANEL

The wheel balancers are equipped with a touch control panel (**Fig. 32 ref. 1**) equipped with a keyboard to interact/operate the controls presented in graphical form on the monitor.

On the monitor are displayed all the instructions for the correct wheel balancing, for example indicating where the operator shall fit adhesive or clip weights and the balancing mode and/or option used, as well as correct wheel rotation for inner/outer weights positioning.



### 14.0 WHEEL BALANCING


#### **14.1 Switching the machine on and off**

Press the "ON" switch (**Fig. 21 ref. 1**), located in the rear part of the equipment.



**IN THE CASE OF PNEUMATIC MODELS, ON STARTING, THE PNEUMATIC MANDREL IS ALWAYS OPENED. ALWAYS KEEP YOUR HANDS AND OTHER PARTS OF THE BODY AWAY FROM THE MOVING MANDREL. ALSO TAKE CARE IF A WHEEL IS ALREADY FITTED ON THE MANDREL, AS THIS COULD BE FORCED OFF THE SHAFT DURING THE OPENING OF THE MANDREL ITSELF.**

Wait a few seconds until the complete loading of the operational program. The equipment is ready to operate when the main screen "Home" appears on the monitor..




**ALL THE PUSH-BUTTONS ON THE LOWER BAR (D) CAN BE SELECTED BY TOUCH.**

- 1 - Programs and measurements acquisition buttons
- 2 - Wheel spin push-button
- 3 - Go to next page
- 4 - Pneumatic mandrel opening/closing (only for GP3.128R model) (generally used in case of emergency)

- 5 – User management (if enabled)  
(user management is not enabled on machine delivery)

At the bottom of the main screen and each screen described below, there will be coloured rectangles (**Fig. 33 ref. B**) located above the icons of identification function (**Fig. 33 ref. C**). These functions are activated, as well as by pressing directly on the functions icons on monitor, also by pressing on the relevant coloured button on the push-button panel (**Fig. 32 ref. 9**). Press the button (**Fig. 33 ref. 3**) to display a second page where you can access the "Technical assistance" menu and the "Run-out" menu (see **Fig. 34**).

Fig. 34




## KEY

- 1 – User menu  
2 – Run-out menu (visible only if the machine is fit or if the Run-out device is enabled)  
3 – Return to previous page

In order to turn off the machine, simply press the "OFF" switch (**Fig. 21 ref. 1**).




**WHEN THE EQUIPMENT IS TURNED OFF LOSES ALL THE MEASUREMENTS AND THE STORED DATA (SIZE, SPINS, USERS, ETC ...). AT RESTARTING, PRESSING THE BUT-**

**TON**  (IN THE CASE HAVE NOT YET BEEN STORED ON THE NEW MEASURES AFTER THE SWITCHING ON), THE MACHINE DOES NOT PERFORM ANY OPERATION.

## 14.2 Balancing programs setting

The setting of the balancing programs can be performed in two ways:

- through the gauge arm (rapid setting);
- through "Measurement being acquired" screen, ap-

pearing when the  button is pressed (**Fig. 33 ref. 1**).

The setting modes are completely different even if they allow to reach the same result (but with different times).

### 14.2.1 Programs rapid setting and measurements through distance-diameter caliper arm

The use of the distance-diameter caliper arm allows the rapid automatic wheel balancing program and the measures entry. From page "Home":


- bring into contact the weights fitting gripper with the inner part of the rim (1 contact only) to select the program "STATIC" (see **Fig. 35**).



Fig. 35



**REPEATEDLY BRINGING THE GAUGE'S ARM (FIG. 36 REF. 1) IN CONTACT WITH THE MANDREL (FIG. 36 REF. 2), THE PROGRAM WILL CYCLE FROM "STATIC" TO "STATIC 1" TO "2 STATIC" THEN RETURNING TO THE BEGINNING.**



**Fig. 36**


- Bring into contact the weights fitting gripper with the inner part of the rim (2 contact points) (see Fig. 35) to select "ALU-S" program.



**REPEATEDLY BRINGING THE GAUGE'S ARM (FIG. 36 REF. 1) IN CONTACT WITH THE MANDREL (FIG. 36 REF. 2), THE PROGRAM WILL CYCLE FROM "ALU-S" TO "ALU-S 1" TO "ALU-S2" THEN RETURNING TO THE BEGINNING.**




**WHENEVER THE DISTANCE-DIAMETER CALIPER AND/OR THE EXTERNAL DATA GAUGE (GAR306 OR GAR304, SEE FIG. 37) (IF ANY) IS KEPT IN POSITION FOR A FEW SECONDS AGAINST THE RIM (UNTIL THE MACHINE MAKES AN APPROPRIATE SOUND NOTIFICATION), THE POSITION IS STORED AND THE VALUES MEASURED IN THE PRE-ARRANGED FIELDS IN THE SELECTED WHEEL BALANCING PROGRAM ARE LOADED.**



**Fig. 37**

**GAR306**



**GAR304**

- After entering all the required measures, you can spin



the wheel by pressing the button and closing the protective guard.

- **Measuring procedure of electronic RUN-OUT with the distance-diameter caliper arm.**

The electronic RUN-OUT measuring device is useful to check if the rim has some imperfections.

To access the run-out measuring screen, proceed as follows:

- from the "Home" page, press the button



(Fig. 38 re. 1) and then the button (see Fig. 39 ref. 1).






Fig. 38




Fig. 39



The screen page below is displayed.

Fig. 40



Place the distance-diameter caliper grippers (**Fig. 41 ref. 1**) on the inner side of the rim, as shown in **Fig. 41**.

Press the green button on the monitor (**Fig. 40 ref. 1**) to start the rim analysis procedure. The circle starts to spin at low speed (30 rpm) and



at the end of the measurement the eccentricity graph appears, as shown in the **Fig. 42**.




Fig. 41




Fig. 42


## KEY


- 1 - Fundamental sine wave (fuchsia-coloured-graph)
- 2 - Graph of detected eccentricity (green)
- 3 - Slider that indicates the current position of the rim ("12 o'clock") (red)
- 4 - Value in mm of the highest peak of imperfection detected on the rim
- 5 - Value in mm of imperfection of the rim at the current position
- 6 - Value in mm of the lowest peak of imperfection detected on the rim
- 7 - Graph deleting button


The green graph (**Fig. 42 ref. 2**) represents exactly the geometric shape of the rim. The more the circle is round and linear, the more the graph is flat, unlike the more the circle has deficiencies, the more the graph is large.



You can follow the eccentricity in the graph by manually turning the rim, the red-coloured-slider (**Fig. 42 ref. 3**), indicates the position of the rim in "12 o'clock" position.


**14.2.2 Programs setting through "Measurement being acquired" screen page**

From the "Home" page, press the  (Fig. 33 ref. 1) button to display the "Measurement being acquired" screen below:






**PRESS THE BUTTON**  (Fig. 33 ref. 1) TO DISABLE AUTOMATIC FUNCTION OF THE DISTANCE-DIAMETER CALIPER ARM WHEEL BALANCING SELECTION, DESCRIBED IN PAR. 14.2.1. TO BE ABLE TO REUSE THE AUTOMATIC FUNCTION TO SELECT THE WHEEL BALANCING PROGRAM WITH GAUGE ARM, IT IS NECESSARY TO RETURN TO "HOME" PAGE, BY PRESSING THE BUTTON .


To select the balancing program, press the programs icon (Fig. 43 ref. 3) or the push-button . The displayed programs selection screen is illustrated as follows:




Press directly on the wished mode icon in order to select it.



**AFTER YOU HAVE SELECTED THE DESIRED PROGRAM, USE THE DISTANCE-DIAMETER CALIPER AND/OR THE EXTERNAL DATA GAUGE (GAR306 OR GAR304) (IF ANY) TO DETECT THE MEASURES REQUIRED BY THE PROGRAM.**



**WHENEVER THE DISTANCE-DIAMETER CALIPER AND/OR THE EXTERNAL DATA GAUGE (GAR306 OR GAR304, SEE FIG. 37) (IF ANY) IS KEPT IN POSITION FOR A FEW SECONDS AGAINST THE RIM (UNTIL THE MACHINE MAKES AN APPROPRIATE SOUND NOTIFICATION), THE POSITION IS STORED AND THE VALUES MEASURED IN THE PRE-ARRANGED FIELDS IN THE SELECTED WHEEL BALANCING PROGRAM ARE LOADED.**


After entering all the required measures, you can spin the wheel by pressing the button  and closing the protective guard.

### 14.3 Indicative display of points where to detect measures/to fit weight



**IT IS VERY IMPORTANT TO REMEMBER THE POINTS SELECTED FOR MEASUREMENT INSIDE THE RIM SINCE DURING THE WEIGHTS FITTING AT "6 O'CLOCK" WITHOUT MOBILE LASER YOU WILL NOT HAVE ANY OTHER REFERENCE. THE POSITIONING IN DEPTH WILL BE AT THE DISCRETION OF THE OPERATOR.**

Depending on the type of program selected, the machine shows on the monitor the guideline points where to take measures and, consequently, where you must apply weights (Fig. 43 ref. 4-5).



#### KEY

- 1 – 1<sup>st</sup> weight fitting point distance
- 2 – Rim diameter
- 3 – Balancing mode
- 4 – Point at which to take the measure/adhesive weight fitting
- 5 – Point at which to take the measure/clip weight fitting
- 6 – Rim width



**IT IS POSSIBLE TO SELECT THE VALUE/PROGRAM TO MODIFY BY PRESSING DIRECTLY ON THE RELEVANT FIELD ON MONITOR (VALID FOR POINTS 1, 2, 3, 6).**



**THE MORE THE POINTS CHOSEN FOR THE PROBING ARE DISTANT FROM EACH OTHER THE MORE THE BALANCING WILL BE EFFECTIVE.**

### 14.3.1 Weights positioning



The monitor displays when it is absolutely necessary that the weight is applied at "12 o'clock" position. Pay particular attention to the content of the weights identification icons since if the following words **H 12** are displayed, then the icon corresponding weight has to be applied at "12 o'clock" position (typical of ALU-S1, ALU-S2 programs).





**IF ALL MEASURES REQUIRED BY THE PROGRAM HAVE NOT BEEN TAKEN/INSERTED, THE MACHINE DOES NOT ALLOW THE WHEEL SPIN TO DETECT THE UNBALANCE.**


### 14.4 Displaying the active/modifiable field

During the various phases of measures detection, the active field turns blue.




Pressing the buttons  or  you can change the value and/or program inside the active field.

NORMALLY DURING THE DETECTION OF MEASUREMENTS, THE 1ST ACTIVE FIELD WILL BE THE ONE FOR THE SELECTION OF THE PROGRAM.



THERE IS A CASE, HOWEVER, IN WHICH THE 1ST ACTIVE FIELD WILL BE THE RIM WIDTH.




THIS CASE WILL OCCUR ONLY IF FROM "HOME" PAGE IS DETECTED ONLY ONE MEASUREMENT INSIDE THE RIM. THE PROGRAM WILL AUTOMATICALLY SET TO "STATIC" BUT IT WILL MAKE IT POSSIBLE (IN CASE OF ABSENCE OF EXTERNAL DATA GAUGE) TO MANUALLY ENTER RIM WIDTH AND TO QUICKLY SWITCH TO THE PROGRAM "DYNAMIC".



### 14.5 Wheel balancing screen page description

After executing the spin of the wheel, the monitor displays a series of important information that helps the operator in his operations and subsequent choices.


Fig. 44



KEY

- 1 - Selected balancing mode
- P1 - Weight to be fitted on rim outer side
- P2 - Weight to be fitted on rim inner side
- 2 - Wheel placed to fit the weight on wheel outer side (arrows both green)
- 3 - Wheel not placed to fit the weight on wheel inner side (blue/black arrows)
- 4 - Wheel balancing suggestions
- 4a - SPOKES Program (program with adhesive weights) (\*)
- 4b - ECO-WEIGHT Program with weight value to be fitted (if the value is of blue, the machine advises not to use it) (\*)
- 4c - STATIC Program (\*) (•)
- 5 - N° user (if selected)
- 6 - Arrows indicating the weight fitting point with distance-diameter caliper arm
- 7 - Wheel repositioning button for weights fitting
- 8 - Display the actual weight
- 9 - Programs and measurements acquisition buttons




10 - By pressing the button  you will see the following page where you can select further programs suggested by the machine.

(\*) By pressing directly on the icon, or the value next to the icon, it goes directly to the balancing program suggested by the machine.


- (•) If you choose the "STATIC" program, the machine will be set for this program (see Par. 14.7.1), and you can no longer go back to this screen page.

Fig. 44a



IF THE GUARD AND REPOSITIONING FUNCTION ARE DISABLED, ON BUTTON 7 YOU WILL SEE



THE  ICON THAT WILL ALLOW THE WHEEL SPIN WITHOUT RETURNING TO THE PREVIOUS PAGE. THE POSITIONING OF THE WHEEL FOR THE APPLICATION OF THE WEIGHTS MUST BE DONE MANUALLY.

### 14.5.1 Balancing mode

The machine has the ability to perform the wheel balancing (weights fitting) in 3 different ways:

- using the distance-diameter caliper arm with weights fitting grippers;
- using the laser at "6 o'clock";
- weights fitting at "6 o'clock" (without the use of lasers).

#### • Weights fitting with distance-diameter caliper arm.

1. Place the adhesive weight on the arm grippers.

Fit the adhesive weight in the pliers of the gauge rod




2. Pull out the gauge until the arrows (Fig. 44 ref. 6) both turn green.
3. Rotate the gauge arm until the weight touches the rim.

Fit weight on the position where pliers touches the wheel



4. Bring the distance-diameter caliper arm into resting position.




5. Press the  button to change the weight fitting side.
6. Proceed in the same way as described in points 1-2-3.



**BEFORE REMOVING THE DIAMETER-DISTANCE CALIPER, PRESS THE BRAKE PEDAL AND HOLD IT DOWN UNTIL THE WEIGHT HAS NOT BEEN APPLIED, ENSURING IN THIS WAY THAT, DURING THESE PHASES, THE WHEEL CAN NOT ROTATE.**

• **Weights fitting with laser (at "6 hours").**



**THE MACHINE (IF PRE-SET WITH FIXED LASER, ON DELIVERY IT IS SET WITH THE OPTION DESELECTED). TO USE THIS MODE, IT IS NECESSARY THAT THE RELEVANT FUNCTION IS ENABLED**  **ON THE MENU "OPTIONS" DESCRIBED IN PAR. 15.1.**



**TO USE THIS WEIGHTS APPLICATION MODE THE OPERATOR MUST REMEMBER THE PRECISE POINT AT WHICH THE MEASUREMENT WAS TAKEN WITH THE DISTANCE-DIAMETER CALIPER ARM.**


At the end of the spin, on the rim at "6 hours" is displayed a laser beam (blade) indicating the axis on which to apply the weight. The positioning of the weight (s) in depth shall be at the discretion of the operator, depending on where remembers taking the measure.



**BE SURE TO APPLY THE WEIGHT (INTERNAL OR EXTERNAL) AS INDICATED BY THE 2 GREEN ARROWS (Fig. 44 ref. 2 or 3) ON THE CORRESPONDING MONITOR SCREEN.**

• **Weights fitting at "6 o'clock" (without the use of lasers).**



**TO USE THIS MODE, IT IS NECESSARY THAT THE RELEVANT FUNCTION IS ENABLED**  **ON THE MENU "OPTIONS" DESCRIBED IN PAR. 15.1.**



**TO USE THIS WEIGHTS APPLICATION MODE THE OPERATOR MUST REMEMBER THE PRECISE POINT AT WHICH THE MEASUREMENT WAS TAKEN WITH THE DISTANCE-DIAMETER CALIPER ARM.**



**USING THIS MODE, THE MACHINE ALLOWS YOU TO APPLY ANY ADHESIVE WEIGHTS THAT WOULD BE APPLIED TO "12 HOURS" TO "6 O'CLOCK". IF, AFTER YOU ENABLE THIS MODE, ON BALANCING PROGRAM APPEARED AGAIN THE **H 12** ICON (ONLY IN THIS CASE) THE ADHESIVE WEIGHT WILL BE APPLIED TO "12 HOURS".**

At the end of the spin, the wheel stops in place to apply the weight at "6 o'clock". The positioning of the weight (s) in depth shall be at the discretion of the operator, depending on where remembers taking the measure.



**BE SURE TO APPLY THE WEIGHT (INTERNAL OR EXTERNAL) AS INDICATED BY THE 2 GREEN ARROWS (Fig. 44 ref. 2 or 3) ON THE CORRESPONDING MONITOR SCREEN.**

## 14.6 Use of machines with disabled automatic gauge

The entry of diameter, width and distance measures of the machine rim must be performed manually. The reading of these measures can be made as follows:

- visual readout on caliper graduated scale (distance);
- values readout on rim (diameter and width);
- width value detection with manual caliper (width) (see **Fig. 45**).




Fig. 45


### 14.6.1 Manual setting of wheel dimensions

In case the operator wants to edit and/or manually enter the wheel dimensions, proceed as follows:

- from the desired measurement mode screen, press directly on the value/field to modify/edit;


- press the buttons  or  until reaching the desired value;

- press on a new value/field to set out the next value.



After entering all the required measures, you can spin



the wheel by pressing the button  and closing the protective guard.

NOTE: In case the distance-diameter caliper was disabled, the displayed page for detected unbalance is as follows:




Fig. 46


In this screen page, in addition to the information of the detected unbalance, there are measurements in mm where you must remove the gauge arm (**Fig. 46 ref. 1-2**) to apply the weights inside the rim.

## 14.7 Standard balancing programs

### 14.7.1 Static

The STATIC program permits balancing wheels by fitting adhesive weights on the outer and inner sides of the rim. Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

### **14.7.2 Static-1**

The STATIC 1 function is a procedure that offsets wheel vibrations using a single weight with clip on a single plane positioned exactly at 12 o' clock.

Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5 "Dynamic balancing" (only for wheel inner side).

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

### **14.7.3 Static-2**

The STATIC 2 function is a procedure that offsets wheel vibrations using a single adhesive weight on a single plane positioned exactly at 12 o' clock.

Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5 "Dynamic balancing" (only for wheel inner side).

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

### **14.7.4 Dynamic**

The DYNAMIC program allows the wheels balancing by fitting two clip adhesive weights: one on the outside and one on the inside rim. Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

### **14.7.5 ALU-S**

The ALU-S program permits balancing wheels by two fitting adhesive weights on the outer and inner sides of the rim. Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.



**14.7.6 ALU-S1**

The ALU-S1 function permits balancing wheels with light alloy rims by fitting adhesive weights on the outer side and weight with clip on inner side of wheel (at 12 o' clock).

Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5 (the inner weight is with clip).

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

**14.7.7 ALU-S2**

The ALU-S2 function permits balancing wheels with light alloy rims by fitting two adhesive weights: one on the outer and one on inner sides of the rim (the inner weight is at 12 o' clock).

Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

**14.7.8 ALU-1**

The ALU-1 function permits balancing wheels with light alloy rims by fitting adhesive weights on the outer and inner sides of the rim at 12 o' clock.

Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as described in Par. 14.5.

At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.




The procedure has now been completed.

**14.7.9 ALU-2**

The ALU-2 function balances wheels with light alloy rims by fitting adhesive weights on the outside and inside of the rim. The position of the outer weight is not visible but hidden inside. Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as for dynamic unbalance.


At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

### **14.7.10 ALU-3**


The ALU-3 function is a procedure that uses mixed weights to offset wheel unbalance: weight with clip on inner side of wheel, adhesive weight on outer side, not visible because inside the rim.  
Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as for dynamic unbalance.  
At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

### **14.7.11 ALU-4**

The ALU-4 function is a procedure that uses mixed weights to offset wheel unbalance: weight with clip on inner side of wheel, adhesive weight on outer side.  
Enter the measurements (see Par. 14.2.1 or 14.6.1) and proceed as for dynamic unbalance.  
At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin.



The procedure has now been completed.

## **14.8 Optional balancing programs**

### **14.8.1 ECO-WEIGHT mode**



**TO USE THE ECO-WEIGHT PROCEDURE IT IS NECESSARY THAT THE DISTANCE-DIAMETER CALIPER ARM IS ENABLED IN THE "OPTIONS" MENU DESCRIBED IN PAR. 15.1.**



**THE ECO-WEIGHT PROCEDURE CAN ONLY BE USED WITH THE PROGRAM ALU-S.**

This procedure represents a modern system for the reset of the unbalance in order to reduce weights consumption. This procedure ensures a fastest execution of the operations, thanks to a lesser number of spins and repositioning.

After making the wheel spin in ALU-S mode, the monitor shows the total of 2 adhesive weights to precisely correct STATIC and DYNAMIC unbalance.



It is possible to fit a single weight at a predetermined distance from the machine, so as to optimise the weight consumption and reduce both the DYNAMIC and any remaining STATIC unbalance as much as possible. Unlike the standard STATIC procedure, the ECO-WEIGHT procedure, though only using one weight, also considerably reduces the DYNAMIC unbalance, because the fitting distance of the weight on the rim is also calculated.


From the ALU-S unbalance results page, if there is

considerable static unbalance, press the button



to display on the following monitor screen:



Press button  to select such procedure and bring automatically the wheel into weight fitting position.




Fig. 47

## KEY

- 1 – Only weight to be fitted
- 2 – Selected balancing mode
- 3 – Residual dynamic unbalance value (if the value is blue it is not to carry out ECO-WEIGHT procedure)
- 4 – Static unbalance value (if the value is blue it is not to carry out ECO-WEIGHT procedure)
- 5 – Residual dynamic unbalance value (if the value is blue it is not to carry out ECO-WEIGHT procedure)
- 6 – Arrows indicating the weight fitting point with distance-diameter caliper arm

Press the brake pedal and fit the adhesive weight inside pliers as shown in **Fig. 48**.

**Fig. 48** Fit the adhesive weight in the pliers of the gauge rod



Pull out the gauge rod until the arrows (**Fig. 47 ref. 6**) turn green.

**Fig. 49** Fit weight on the position where pliers touches the wheel




At the end of the procedure, the wheel balancing conditions can be checked by performing a trial spin. The ECO-WEIGHT procedure has now been completed.

**IMMEDIATELY AFTER HAVING SELECTED THE ECO-WEIGHT PROCEDURE, YOU CAN KNOW IN ADVANCE THE TWO DYNAMIC UNBALANCES AND THE STATIC RESIDUE IN ORDER TO DECIDE WHETHER IT IS CONVENIENT TO CONTINUE (SEE FIG. 47).**

**IF BOTH DYNAMIC UNBALANCES AND STATIC RESIDUE ARE SHOWN AS WHITE VALUES ON THE MONITOR, THIS MEANS THAT THE PROGRAM HAS DECIDED THAT IT IS BETTER TO CONTINUE. WHILE IF, ON THE OTHER HAND, ONE OR MORE VALUES ARE BLUE, THE PROGRAM SUGGESTS USING THE STANDARD ALU-S PROCEDURE.**



**PRESS BUTTON  ONCE. THE TWO RESIDUAL DYNAMIC UNBALANCES WILL BE DISPLAYED ON MONITOR.**

**PRESS BUTTON  ONCE MORE. THE CALCULATED REAL STATIC WEIGHT AND THE RESIDUAL STATIC WEIGHT WILL BE DISPLAYED ON SCREEN.**

**IF YOU ARE NOT WISHING TO OPERATE WITH THE ECO-WEIGHT PROCEDURE, PRESS BUTTON**



**, ONCE MORE. THE ALU-S UNBALANCE VALUES WILL BE DISPLAYED AGAIN.**

**WHILE IF YOU WISH TO OPERATE WITH THE ECO-WEIGHT PROCEDURE, PRESS BUTTON**



**FOR**



**A LONGER TIME (OR KEY ) TO GO BACK TO THE RESIDUAL DYNAMIC/ECO-WEIGHT WEIGHT DISPLAY SCREENS.**

### **14.8.2 SPLIT mode**

The Split procedure proves useful when the dynamic unbalance of a wheel is fairly high and the weight to be fitted is not available, for instance a 100 g weight. It's possible then to correct the unbalance dividing the amount of weight into two weights of smaller size.

The Split procedure eliminates errors by using the "DYNAMIC" program, as for example by manually fitting two 50 g weights close to one another, instead of only a 100 gr one.

**For example:**

100 g WEIGHT  
TO BE FITTED TO CORRECT  
UNBALANCE



TWO SMALLER WEIGHTS (50g)  
FITTED MANUALLY





TWO SMALLER WEIGHTS (55g)  
USING SPLIT PROCEDURE



Proceed to "DYNAMIC" unbalance measurement displaying by performing a standard wheel spin.



Once detected the unbalance values, verify that the machine displays the ability to use the "SPLIT" option

. Press button to shift to the next screen page.



IN CASE THERE IS NO "SPLIT" FUNCTION ON THE LEFT SIDE

MENU, PRESS PUSH-BUTTON TO MOVE TO THE NEXT SCREEN PAGE, ILLUSTRATED BELOW.



Press button on the lower bar to enter the "SPLIT" function.

On the monitor screen will be displayed where you must enter the value of the weights to be fitted.

Press button to select the outer weight to edit.

Press buttons or to increase or decrease the total weight to be fitted.



THE BLUE VALUE INDICATES WHICH VALUE IS ACTIVE AND YOU ARE EDITING.



THE HIGHER THE CHOSEN WEIGHTS VALUE IS, THE MORE THEY WILL BE SPACED.


After choosing the value of the weights to be fitted,

press button to position the wheel for the application of the 1st clip weight.






**THE TWO GREEN ARROWS INDICATE THAT THE WHEEL IS PROPERLY POSITIONED FOR THE APPLICATION OF THE 1ST WEIGHT.**

Fit the clip weight of the chosen value at 12 o'clock on the outside of the wheel. Press again button  to position the wheel for the fitting of the 2<sup>nd</sup> clip weight.



Fit the clip weight of the chosen value at 12 o'clock on the outside of the wheel. Press button  to highlight the value of the weights to be fitted on the inside of the wheel.



Repeat the above steps for the weights to be fitted inside the wheel. At the end perform again a checking spin to see that you have applied the weights correctly.


### 14.8.3 Weights hidden behind spokes mode

Adhesive correction weight positioning may not look attractive on some types of rims. In this case, the "weights hidden behind spokes" mode can be used. This splits any correction weight on the outer side into two parts to be hidden behind the rim spokes. It can be used in both ALU-S or STATIC modes.


Display the ALU-S or STATIC, unbalance measurements, by performing a standard wheel spin.



Once detected the unbalance values, verify that the machine displays the ability to use the "spokes" options (**Fig. 44a**).

Press icon  to access directly the corresponding function.


On the monitor the next screen page will be displayed:



Bring any spoke upwards at "12 o'clock" position and



press the button to confirm and continue.



Lead to "12 hours" the 2nd spoke. The machine will automatically calculate the total number of spokes. If the value shown on the screen (A) is correct, press the



button

The machine automatically calculates weight position in two positions hidden behind the spokes. The monitor shows the amount of weight to be applied behind the FIRST spoke and the rim will reach the position to apply the FIRST weight.



Extract the gauge rod, and fit the FIRST weight in the position shown by the machine, as explained in



Par. 14.5.1. Press the button to confirm that they have applied the FIRST weight and to automatically position the wheel for the fitting of the 2nd weight. The monitor shows the amount of weight to be applied behind the SECOND spoke.

Pull out the gauge rod and fit the SECOND weight in the position shown by the machine, as done for the first weight.



Press the button to confirm that you have applied the SECOND weight and get back to the initial situation of unbalance, before performing the "weights hidden behind the spokes" procedure. Perform another test spin.

The "weights hidden behind spokes" procedure is completed.

Complete the operation by adding an additional weight inside the rim as required by the selected mode (ALU-S or STATIC).


#### 14.8.4 Matching mode

The Matching procedure offsets strong unbalance, reducing the weight quantity to be fitted on the wheel to achieve balancing. This procedure permits reducing unbalance as much as possible by offsetting the tyre unbalance with that of the rim in any used program.

Proceed to unbalance measurement displaying by performing a standard wheel spin.



**THE MATCHING PROCEDURE CAN BE CARRIED OUT ONLY IF THE STATIC UNBALANCE IS > 30 G.**



Once detected the unbalance values, verify that the machine displays the ability to use the "matching" options (Fig. 44a).




Press button to shift to the next screen page.




Press button to shift to access the corresponding function.

The following screen will appear on the monitor:



**STEP 1.** Move the slider on the flange to the "12 o'clock" position. Make a reference mark, using chalk for instance, on the rim and tyre, in line with the arrow on the flange, so as to be able to fit the rim back on in the same position on the machine.




Make a reference mark on the rim and tyre, in line with the arrow on the flange



Press button  to confirm that step 1 has been completed.

On the display the next screen page will be displayed:




**STEP 2.** Remove the wheel from the wheel balancer. Remove the tyre and turn it on the rim by 180°.



Fit the wheel back on the wheel balancer, positioning the reference mark on the rim in line with the arrow on the flange.

Position the reference mark on the rim in line with the arrow on the flange.



Position the tyre reference mark on the opposite side to the arrow on the flange.



Press button  to confirm that step 2 has been completed.


On the display the next screen page will be displayed suggesting to perform a spin of the wheel.



After having fitted wheel back in position, close the protection guard to make an automatic wheel spin. At the end of the spin the monitor will display the following screen:



Fig. 50




In this screen you will see the dynamic unbalance that the wheel had before performing the operation (Fig. 50 ref. 1), the dynamic unbalance after having rotated the tyre of 180° compared to the rim (Fig. 50 ref. 2) and the unbalance which can be obtained following the directions of the machine (Fig. 50 ref. 3).

**STEP 3.** If the value of possible unbalance reduction is high, you can proceed as follows:

- Cancel the previously made reference marks. Put new signs, as described below.



- Press the button  to bring the wheel into position.



Make the reference mark on RIM at 12 o'clock (see Fig. 51).

reference mark on  
RIM





Fig. 51



- Press the button  to bring the wheel into position.



Mark the reference mark on the TIRE at "12 o'clock" position.




Press button  to confirm that step 3 has been completed.

**STEP 4.** Remove the wheel from the wheel balancer. Dismount and remount the tyre on the rim so as to bring the two reference marks (rim and tyre) to coincide. Refit the wheel on the balancer (see Fig. 52) with the two reference marks next to the arrow on the flange.

reference mark on  
TYRE and reference  
mark on RIM shall  
coincide

Fig. 52



Press button  to confirm that step 4 has been completed.

Perform another spin closing the protection guard, to check the expected unbalance reduction and correct any residual unbalance, as described in Chap. 14.5.1.



## **14.9 Special balancing programs**


### **14.9.1 Pax**

The PAX mode is a special procedure specially devised to balance wheels using the "PAX System ®". 2 adhesive weights on different planes are used on rim inner side.

To launch a PAX measurement, proceed as follows:

- Make sure there are no stones and/or mud on the wheel. Remove any counterweights. Fit the wheel and make sure it is properly fastened (see Chap. 12).

- Press  button from "Home" page. On the screen that appears, press the programs icon  to switch to measuring mode selection screen below.



The machine will be configured as follows to perform the measurement and on the video screen will appear the indication of the specific measures of the selected wheel type.

Close the protection guard to perform the automatic wheel spin.

In just a few seconds, the wheel runs at normal speed and the monitor shows wheel rotation.

After the spin, the wheel stops automatically, taking into account the measured unbalance so that the fitting position of the weight will be at 12 o' clock.



The the monitor show the weight required to correct the unbalance.

Open the protection guard and proceed to fit the adhesive weight as shown for the ALU-S mode (see Par. 14.7.5).

## **14.10 Recalculation Function**

After making a spin, the wheel automatically stops, indicating the weight/sto be fitted and its/their position. In case the operator does not want the type of wheel balance proposed by the machine (program type, weights size, etc ...), proceed with the re-calculation of the wheel balancing without rerunning the spin of the wheel.

To do this, proceed as described below:

- press the button  to return to the measures detection/program selection page;
- select a new balancing program as indicated in Par. 14.2.2;
- take with the gauge arm the measures required by the selected program;
- press button  to perform the re-calculation. The monitor will display the weights and the positions in which they will be applied.

If also in this case the operator should decide to further modify the balancing program, it is sufficient to proceed as described above without having to spin the wheel.



When the result of the recalculation does not satisfy the operator, it is recommended to do a spin of the wheel to confirm the findings from the operation of recalculation itself.

After the launch of the wheel, the machine, in addition to displaying the unbalance value, draw up automatically all the programs measurement fields that are consistent with those measures that were taken previously and at the same time erases all measures which are not consistent.

### 14.11 Motorbike Mode wheel balancing

By enabling the "motorbike wheel balancing" function, the wheel balancers can also balance motorbike wheels.

Before detecting the wheel sizes (see Par. 14.2.2), select motorcycle wheel balancing mode proceeding as described below:

press button  and then button . On the screen that appears, press on the program icon (ex. **DYN**) to switch to programs and measurements acquisition selection screen below.



Press directly on the wished balancing mode icon in order to select it.



At the end press push button

The machine will be configured as follows to perform the measurement in the desired mode and on the screen will appear an indication showing the measures that will be acquired.

The "motorcycle" mode automatically recalculates the wheel distance measurement, increasing this by the length of the optional extension GAR181 A1.

To fit the extension (**Fig. 53 ref. 2**), first press the threaded ring nut (**Fig. 53 ref. 1**) in the hole provided and then screw the plastic terminal (see **Fig. 53**).



**THE EXTENSION WILL ONLY HAVE TO BE SCREWED UP WHEN BALANCING IS PERFORMED IN "MOTORBIKE" MODE.**







Fig. 53

Balancing procedures are identical for both modes (car/motorbike).

By selecting motorbike, besides DYNAMIC balancing (see Par. 14.7.4) STATIC balancing and/or ALU-S (Par. 14.7.1 and/or 14.7.5) can also be performed.

## 15.0 USER MENU (OPTIONS AND CALIBRATION)

From the main page "Home" press the button  to move to the next screen page and the button  to access the user menu. On the monitor, the following screen appears where you can enter the password.





The user login password is: **1234**. After entering the correct password you will see the following screen:





### 15.1 Options menu


Press the button  to display the monitor screen to enable/disable options as shown below:





Press button  to display the 2° option screen page reported as follows.



To enable / disable individual functions simply highlight the icon using the buttons  and/or 

and press the button .

Pressing the button  may involve, besides, the change in the unit of measure from "mm" to "inch" and vice versa (where applicable) or access to a sub-screen for values settings values (see Par. 15.1.1 or 15.1.2). After you select/deselect the desired options, exit the

menu by pressing the .

## List of available options



Enable/disable the protection guard/spin (enabled on machine delivery).



Enable/disable the distance/diameter detection caliper (enabled on machine delivery).



Enable/disable the display of static threshold after each spin (enabled on machine delivery).




It allows you to set the thresholds for each of the balancing mode weights (see Par. 15.1.1).



Enable/disable the lock function for caliper arm in position (disabled on machine delivery).




It allows you to change the unit of measurement of the weights from grams to ounces and vice versa.




It allows you to enable/disable the width function detected by GAR304 or GAR3067 (enabled when fitted as standard on the machine).




Enable/disable the ECO-WEIGHT function (enabled on machine delivery).



Enable/disable the positioning of weights at "6 o'clock" (disabled on machine delivery).



Enable/disable the pneumatic brake after the spin (disabled on machine delivery).



It allows you to change the unit of measure of the distance of the weights fitting point from mm to inches and vice versa.



Enable/disable the led light (enabled if mounted on the machine).




Enable/disable the dynamic residues in the ECO-WEIGHT function (enabled on machine delivery).




Enable/disable the functions of motor-bike balancing (disabled on machine delivery).




Enable/disable the encoder mounted on the spin motor (disabled on machine delivery).




It allows you to change the unit of measurement of the rims width from mm to inches and vice versa.




It allows you to set the size values of weights (see Par. 15.1.2).



Enable/disable the RUN-OUT functions (enabled on machine delivery).



Enable/disable machine print functions (disabled on machine delivery).



It allows the setting of the retrieval of the measures by eye: readout of measures printed on the rim and the graduated scale of the distance-diameter caliper (disabled on machine delivery).

NOTE: it is activated only if distance-diameter caliper is disabled.




Enable/disable the use of the manual caliper to measure rim width (disabled on machine delivery).


NOTE: it is activated only if distance-diameter caliper is disabled.




It allows you to change the unit of measurement of the rim diameter from mm to inches and vice versa.



Enable/disable the functions of weights positioning laser (GAR311) (disabled on machine delivery).



Enable/disable the repositioning of the wheel at the end of the spin (enabled on machine delivery).



Enable/disable the user function (disabled on machine delivery).

### 15.1.1 Lower weight limit

Correction weight below a certain limit is normally shown equal to zero. This limit can be set from 10 g to 1 g.


At the end of the spin however, by pressing the button



, the weight can be displayed with max resolution of 1 g, not considering the set lower limit.



**IN THE PLANT, THE LOWER LIMIT FOR THE DYNAMIC WHEEL BALANCING MODE IS SET TO 5 g. THE LOWER LIMIT FOR ALL THE OTHER MODES IS SET TO 7 g.**





**KEY**

- 1 - Lower weight limit in the DYNAMIC program to display "OK" (default value 5 g)
- 2 - Lower weight limit in the ALU-STATIC program to display "OK" (default value 7 g)
- 3 - Weights display resolution (default value 5 g)
- 4 - Weight reduction % in the ECO-WEIGHT (0 ÷ 200) (default value 100)


### 15.1.2 Setting adhesive weight dimensions and static threshold percentage

To ensure the balancing machine precisely calculates the dimensions and total adhesive weights, set the height (thickness) and width of the adhesive weights at your disposal (see **Fig. 55**).

**Fig. 55**



To carry out this setting, press the icon . You will see the following screen:



**KEY**

- 1 - Thickness (height) weights (default value 4 mm)
- 2 - Weights width (default value 19 mm)

From this screen page, change the size values of weights

using the buttons  and .






**THE BLUE-COLOURED-VALUE IS THE ACTIVE FIELD AND THE MODIFIABLE ONE.**


### 15.1.3 User management

The "User Management" function is disabled on machine delivery. To enable it, proceed as described in Para 15.1. After enabling, the icon will be displayed on every page (**Fig. 56 ref. 1**).

The wheel balancers can be used simultaneously by 4 different users.




Press button  shown on the monitor (**Fig. 56 ref. 2**) or select the field (**Fig. 57 ref. 1**) to display the screen below:



Press any of the available numbers on the buttons at the bottom of the page to select the corresponding user. The system stores the data relating to the last performed spin according to the different operators. You can recall the desired user each time the program displays the specific button (**Fig. 56 ref. 2** and **Fig. 57 ref. 1**). The measurements stored for each user are lost when the machine is switched off.


User management is valid for any wheel balancer function.



## **15.2 Machine calibration**



Press the button  (Fig. 54 ref. 2) to display the following screen page on monitor:




### KEY

- 1 - Mandrel "Ø" calibration
- 2 - Weight measurement sensors calibration
- 3 - Gauge calibration
- 4 - Touch monitor calibration


### **15.2.1 Mandrel "Ø" calibration**



Press the button  to display the following screen page on the monitor:




After making sure that the spindle is unloaded (no wheel or mounted accessories) and in the case of closed

pneumatic mandrel, press the button  and close the guard. The spindle will rotate for a few minutes until you see the screen below:



At this point the machine has all its measuring fields.

Press button  to return to calibrations screen page.



### 15.2.2 Weight measurement sensors calibration




**ASSEMBLE A BALANCED WHEEL ON THE SPINDLE AND PERFORM THE SPINDLE Ø CALIBRATION PROCEDURE DESCRIBED IN PAR. 15.2.1 (WITH WHEEL MOUNTED).**


- Press on the button  to display the following screen page:



- Set the size of the rim on the mandrel using the distance-diameter caliper arm and the external data gauge (if present) or manual caliper.




- Press the button  and close the guard to perform the 1st spin of the wheel without weights.
- At the end, on the monitor will appear the following screen, saying that you should apply a weight of 100 g to the "12 o'clock" outer rim.




**APPLY THE WEIGHT AT A POINT IN WHICH BOTH SIDES OF THE RIM THERE IS THE POSSIBILITY OF APPLYING A CLIP WEIGHT OF 100 g.**

- Apply the weight and position it perfectly to the "12 o'clock".




- Press the button  and close the guard to perform the 2nd spin of the wheel (100 g weight placed on the outside of the wheel).
- At the end the following screen will appear on the monitor, suggesting to remove the weight of 100 g previously applied on the outer side and apply it on the inside of the rim.




- Turn manually the wheel until you have the weight of 100 g on the outer side at "12 o'clock".
- Press the brake pedal and hold it down during the whole the following operation to avoid unexpected rotation of the spindle.
- Remove the weight from 100 g from the outside of the wheel and apply it on the inner side at "12 o'clock".
- Close the guard to perform the 3rd spin of the wheel (100 g weight placed on the inside wheel).


At the end of the rotation, the video screen below will be displayed to indicate that the operation is finished.



**WHEN THE OPERATION IS CONCLUDED, REMOVE THE WHEEL FROM THE SPINDLE AND PERFORM A COMPLETE CALIBRATION PROCEDURE Ø SPINDLE AS DESCRIBED IN PAR. 15.2.1.**

**15.2.3 Gauge calibration**


Press the button  to display the following screen page on the monitor:



KEY


- 1 - Distance-diameter caliper calibration
- 2 - External data gauge calibration

**Distance-diameter caliper calibration**


Press the button  to display the following screen page on the monitor:



Place the gauge (Fig. 58 ref. 1) on the mandrel flange (Fig. 58 ref. 2).



The following screen will appear on the monitor to indicate the measured values:



- The value next to the symbol "scale" (Fig. 59 ref. 1) must be equal to the value positioned above the gauge (Fig. 59 ref. 2)  $\pm 1$  mm.

- Press push button .


The following screen will appear on the monitor:




- Place the gauge as shown in the following figure:







- Press push button . Wait a few seconds until you see the following screen:



- Place the gauge against the mandrel in the lower part of it but on a smaller diameter than before as indicated on the image on the monitor.



- Press push button . On the monitor the next screen page will be displayed:



Measure the exact diameter of a rim (see **Fig. 60**) and place it on the screen on the monitor by pressing the



or



buttons.

**Fig. 60**





- Fit the measured wheel on the balancer and lock it on the spindle.
- Turn the gauge ferrule (**Fig. 61 ref. 1**) on the inner edge of the wheel upwards (see **Fig. 61**).



**Fig. 61**





- Press button  to end the operation. On the monitor the next screen page will be displayed:



The calibration of the distance-diameter caliper is finished.

**Calibration of external data gauge (optional)**

Press the button  to display the following screen page on the monitor:




**TO PERFORM THIS CALIBRATION, THE SPINDLE MUST BE UNLOADED (NO WHEEL OR ACCESSORIES MOUNTED ON IT) AND WITH CLOSED PNEUMATIC MANDREL.**


Move the tip of the width measuring device (**Fig. 62-63 ref. 1**) by the mandrel end (**Fig. 62-63 ref. 2**) (in case of pneumatic mandrel, move it next to upper edge of the closed mandrel).

SCREW CHUCK

Fig. 63




GAR306




PNEUMATIC MANDREL

SCREW CHUCK

Fig. 62





GAR304




PNEUMATIC MANDREL





Press button . On the monitor the next screen page will be displayed:



Move the tip of the width measuring device (**Fig. 64 ref. 1**) in line with the outer surface of the flange (**Fig. 64 ref. 2**).



Press button . At the end of the operation, the following screen will appear on the monitor:




The calibration of the external data gauge is finished.

### 15.2.4 Touch monitor calibration



Press the button  to display the following screen page on the monitor:



Press the intersection of the lines that appear on the monitor. The points on which you need to press will be 4 and positioned near the corners of the monitor. The calibration of the monitor is finished.

## 16.0 ERROR SIGNALS

During wheel balancer operation, if wrong commands are given by the operator or device faults occur, an error code may appear on the monitor screen.

Below is a troubleshooting chart.

<b>Error code</b>	<b>Description</b>
2	Planned wheel speed not reached
3	Calibration overcoming
4	Wheel speed stability out of tolerance
5	Encoder calibration error
6	Encoder samples not sufficient
7	Mandrel calibration error
8	Piezo calibration values out of tolerance
9	Wheel rotations not completed
10	Pneumatic chucking table open
11	Incorrect gain calibration
12	Distance-diameter caliper value not released
13	Distance-diameter caliper value not released
14	Firmware error
15	Runout samples not sufficient
17	External data gauge enabled
27	Rotate the wheel to make a complete rotation
28	Piezo calibration error
29	Distance out of tolerance level
31	Distance-diameter caliper released
32	Parameters format incompatible



## 17.0 ROUTINE MAINTENANCE



**BEFORE CARRYING OUT ANY ROUTINE MAINTENANCE OR ADJUSTMENT PROCEDURE, POSITION THE MAIN SWITCH "0", DISCONNECT THE MACHINE FROM THE ELECTRICITY SUPPLY USING THE SOCKET/PLUG COMBINATION AND CHECK THAT ALL MOBILE PARTS ARE AT A STANDSTILL.**



**BEFORE EXECUTING ANY MAINTENANCE OPERATION, MAKE SURE THERE ARE NO WHEELS LOCKED ONTO THE MANDREL.**



**PNEUMATICALLY UNPLUG THE MACHINE (ONLY FOR GP3.128R MODEL).**

To guarantee the efficiency and correct functioning of the machine, it is essential to carry out daily or weekly cleaning and weekly routine maintenance, as described below.

Cleaning and routine maintenance must be conducted by authorized personnel and according to the instructions given below.

- Remove deposits of tyre powder and other waste materials with a vacuum cleaner.

**DO NOT BLOW IT WITH COMPRESSED AIR.**

- Do not use solvents to clean the pressure regulator.



**ANY DAMAGE TO THE MACHINE DEVICES RESULTING FROM THE USE OF LUBRICANTS OTHER THAN THOSE RECOMMENDED IN THIS MANUAL WILL RELEASE THE MANUFACTURER FROM ANY LIABILITY!!**


**18.0 TECHNICAL DATA**

	<b>G3.128R</b>	<b>GP3.128R</b>
Wheel max. weight (Kg)	70	
Max. absorbed voltage (W)	200	
Power supply	110 - 230V 50/60 Hz 1 ph	
Balancing precision (g)	± 1	
Balancing speed (rpm)	< 100	
Rim width setting (inches)	1.5" ÷ 22"	
Rim diameter setting (inches)	10" ÷ 26" (manually up to 30")	
Max wheel diameter inside protection (inches)	40"	
Max wheel width inside protection (mm)	560	
Sound emission level (dBA)	<70	
Cycle time (sec)	6	
Weight (Kg)	90	



**18.1 Dimensions**

Fig. 65



## 19.0 STORING


If storing for long periods disconnect the main power supply and take measures to protect the machine from dust build-up. Lubricate parts that could be damaged from drying out.

## 20.0 SCRAPPING

When the decision is taken not to make further use of the machine, it is advisable to make it inoperative by removing the connection pressure hoses. The machine is to be considered as special waste and should be dismantled into homogeneous parts. Dispose of it in accordance with current legislation.

### **20.1 Instructions for the correct management of waste from electric and electronic equipment (WEEE) according to the Italian legislative decree 49/14**

In order to inform the users on the correct way to dispose the product (as required by the article 26, paragraph 1 of the Italian legislative decree 49/14), we communicate what follows: the meaning of the crossed dustbin symbol reported on the equipment indicates that the product must not be thrown among the undifferentiated rubbish (that is to say together with the "mixed urban waste"), but it has to be managed separately, to let the WEEE go through special operations for their reuse or treatment, in order to remove and dispose safely the waste that could be dangerous for the environment and to extract and recycle the raw materials to be reused.



## 21.0 REGISTRATION PLATE DATA



**The validity of the Conformity Declaration enclosed to this manual is also extended to products and/or devices the machine model object of the Conformity Declaration can be equipped with.**





**ATTENTION: DO NOT TAMPER WITH, CARVE, CHANGE OR REMOVE THE MACHINE IDENTIFICATION PLATE; DO NOT COVER IT WITH PANELS, ETC., SINCE IT MUST ALWAYS BE VISIBLE.**

**Said plate must always be kept clean from grease residues or filth generally.**

*WARNING: Should the plate be accidentally damaged (removed from the machine, damaged or even partially illegible) inform immediately the manufacturer.*

## 22.0 FUNCTIONAL DIAGRAMS


Here follows a list of the machine functional diagrams.



G3.128R - GP3.128R

**ELECTRICAL AND PNEUMATIC  
CONNECTION DIAGRAM**

1297-M012-0\_R



**KEY**

- |  |  |
|--|--|
| <p>1 - Display 7"</p> <p>2 - Monitor card 16:9 VGA</p> <p>3 - 200W card not programmed</p> <p>4 - Transformer</p> <p>5 - Tilting switch</p> <p>6 - DC motor</p> <p>7 - Display connection flat cable</p> <p>8 - Push-button panel with 7 keys</p> <p>9 - Led light</p> <p>10- Motor support ground cable</p> <p>11 - Electromagnet connection cable</p> <p>12- Cable from switch to transformer</p> <p>13- Fuse</p> <p>14- Touch-screen extension cables</p> <p>15- Front piezo cables</p> <p>16- Rear piezo cables</p> <p>17- Phonic wheel encoder cables</p> | <p>18 - Distance-diameter caliper cables</p> <p>19 - Cable for wheel micro protection</p> <p>20 - Power supply cable</p> <p>21 - Card</p> <p>22 - Cable for solenoid valve EVC</p> <p>23 - Cable for solenoid valve EVO</p> <p>24 - Potentiometer extension cable</p> <p>25 - Ultrasound sensors extension cable</p> <p>26 - Potentiometer with cable</p> <p>27 - Cable for solenoid valve EVB</p> <p>28 - Runout keyboard extension cable</p> <p>29 - Cable for micro pedal</p> <p>30 - Pneumatic tightening diagram (only for GP3.128R)</p> <p>31 - Tightening drive cylinder</p> <p>32 - 5/2 NC solenoid valves</p> <p>33 - Separating filter</p> |
|--|--|



1297-R012-0\_R

**G3.128R**  
**GP3.128R**

- I** 23.0 LISTA DEI COMPONENTI
- GB** 23.0 LIST OF COMPONENTS
- D** 23.0 TEILELISTE
- F** 23.0 LISTE DES PIÈCES DETACHÉES
- E** 23.0 LISTA DE PIEZAS



**GLI ESPLOSI SERVONO SOLO PER L'IDENTIFICAZIONE DELLE PARTI DA SOSTITUIRE. LA SOSTITUZIONE DEVE ESSERE EFFETTUATA DA PERSONALE PROFESSIONALMENTE QUALIFICATO.**



**THE DIAGRAMS SERVE ONLY FOR THE IDENTIFICATION OF PARTS TO BE REPLACED. THE REPLACEMENT MUST BE CARRIED OUT PROFESSIONALLY QUALIFIED PERSONNEL.**



**DIE ZEICHNUNGEN DIENEN NUR ZUR IDENTIFIZIERUNG DER ERSATZTEILE. DIE ERSETZUNG MUSS DURCH QUALIFIZIERTES PERSONAL ERFOLGEN.**



**LES DESSINS NE SERVENT QU'À L'IDENTIFICATION DES PIÈCES À REMPLACER. LE REMPLACEMENT DOIT ÊTRE EFFECTUÉ PAR UN PERSONNE PROFESSIONNELLEMENT QUALIFIÉ.**



**LOS DIBUJOS EN DESPIECE SIRVEN ÚNICAMENTE PARA IDENTIFICAR LAS PIEZAS QUE DEBEN SUSTITUIRSE. LA SUSTITUCIÓN DE PIEZAS DEBE EFECTUARLA EXCLUSIVAMENTE PERSONAL PROFESIONALMENTE CUALIFICADO.**

- Per eventuali chiarimenti interpellare il più vicino rivenditore oppure rivolgersi direttamente a:
- For any further information please contact your local dealer or call:
- Im Zweifelsfall ober bei Rückfragen wenden Sie sich bitte an den nächsten Wiederverkäufer oder direkt an:
- Pour tout renseignement complémentaire s'adresser au revendeur le Plus proche ou directement à:
- En caso de dudas, para eventuales aclaraciones, póngase en contacto con el distribuidor más próximo ó diríjase directamente a:

Technical services: **RAVAGLIOLI S.p.A.** - Via 1° Maggio, 3 - 40037 Pontecchio Marconi - Bologna Italy  
Phone (+39) 051 6781511 - Telex 510697 RAV I - Fax (+39) 051 846349 - e-mail: [aftersales@ravaglioli.com](mailto:aftersales@ravaglioli.com)



RAVAGLIOLI S.p.A.

**LISTA DEI COMPONENTI  
LIST OF COMPONENTS  
TEILELISTE  
LISTE DES PIÈCES DÉTACHÉES  
LISTA DE PIEZAS**


**Pag. 2 di 23**

G3.128R - GP3.128R

1297-R012-0\_R

**SOMMARIO - SUMMARY - INHALT  
SOMMAIRE - SUMARIO**

<p><b>Tavola N°1 - Rev. 0</b> _____ <b>3</b>  <i>ASSIEME GENERALE            MAIN ASSEMBLY            GENERALSATZ            ASSEMBLAGE GENERAL            JUNTO GENERAL</i></p>	<p><b>Tavola N°9A - Rev. 0</b> __ <b>129690610</b>..... <b>14</b>  <i>GRUPPO PEDALE FRENO            BRAKE PEDAL UNIT            BREMSE PEDALSATZ            GROUPE PÉDAL FREIN            GRUPO PEDAL FRENO</i></p>
<p><b>Tavola N°2 - Rev. 0</b> __ <b>129690073</b>..... <b>5</b>  <i>GRUPPO MOTORE            MOTOR UNIT            MOTORSATZ            GROUPE MOTEUR            GRUPO MOTOR</i></p>	<p><b>Tavola N°9B - Rev. 0</b> __ <b>129690590</b>..... <b>15</b>  <i>GRUPPO PEDALE FRENO            BRAKE PEDAL UNIT            BREMSE PEDALSATZ            GROUPE PÉDAL FREIN            GRUPO PEDAL FRENO</i></p>
<p><b>Tavola N°3A - Rev. 0</b> __ <b>129690090</b>..... <b>6</b>  <i>GRUPPO ROTANTE COMPLETO            COMPLETE ROTARY UNIT            KOMPLETTER ROTIERENDER SATZ            GROUPE ROTATIF COMPLET            GRUPO GIRATORIO COMPLETO</i></p>	<p><b>Tavola N°10 - Rev. 0</b> __ <b>129793070</b>..... <b>16</b>  <i>GRUPPO ELETTRONICA            ELECTRONICS UNIT            ELEKTRONIKSATZ            GROUPE ÉLECTRONIQUE            GRUPO ELECTRÓNICA</i></p>
<p><b>Tavola N°3B - Rev. 0</b> __ <b>129690030</b>..... <b>7</b>  <i>GRUPPO ROTANTE COMPLETO            COMPLETE ROTARY UNIT            KOMPLETTER ROTIERENDER SATZ            GROUPE ROTATIF COMPLET            GRUPO GIRATORIO COMPLETO</i></p>	<p><b>Tavola N°11 - Rev. 0</b> __ <b>129690341</b>..... <b>17</b>  <i>GRUPPO IMPIANTO ELETTRICO            ELECTRICAL SYSTEM UNIT            SATZ VON ELEKTROANLAGE            GROUPE INSTALLATION ÉLECTRIQUE            GRUPO INSTALACIÓN ELÉCTRICA</i></p>
<p><b>Tavola N°4 - Rev. 0</b> __ <b>129690292</b>..... <b>8</b>  <i>GRUPPO FRENO            BRAKE UNIT            BREMSATZ            GROUPE FREIN            GRUPO FRENO</i></p>	<p><b>Tavola N°12 - Rev. 0</b> __ <b>129390311</b>..... <b>18</b>  <i>IMPIANTO SERRAGGIO PNEUMATICO            PNEUMATIC TIGHTENING SYSTEM            ANLAGE FÜR PNEUMATISCHE AUFSPANNUNG            SYSTÈME SERRAGE PNEUMATIQUE            SISTEMA APRIETE NEUMÁTICO</i></p>
<p><b>Tavola N°5 - Rev. 0</b> __ <b>129792570</b>..... <b>9</b>  <i>GRUPPO TELAIO            FRAME UNIT            RAHMENSATZ            GROUPE CHASSIS            GRUPO ESTRUCTURA</i></p>	<p><b>Tavola N°13 - Rev. 0</b> __ <b>129791580</b>..... <b>19</b>  <i>GRUPPO PROTEZIONE RUOTA            WHEEL PROTECTION UNIT            SATZ FÜR RADSCHUTZ            GROUPE PROTECTION ROUE            GRUPO PROTECCIÓN RUEDA</i></p>
<p><b>Tavola N°6 - Rev. 0</b> __ <b>129792600</b>..... <b>10</b>  <i>GRUPPO PLANCIA            BOARD UNIT            BRETTSATZ            GROUPE PLANCHE            GRUPO TABLERO</i></p>	<p><b>Tavola N°14A - Rev. 0</b> _ ..... <b>20</b>  <i>DOTAZIONE A            A EQUIPMENT            AUSSTATTUNG A            DOTATION A            DOTACION A</i></p>
<p><b>Tavola N°7A - Rev. 0</b> __ <b>129690331</b>..... <b>11</b>  <i>GRUPPO CALIBRO            TESTER UNIT            KALIBERSATZ            GROUPE CALIBRE            GRUPO CALIBRE</i></p>	<p><b>Tavola N°14B - Rev. 0</b> _ ..... <b>21</b>  <i>DOTAZIONE B            B EQUIPMENT            AUSSTATTUNG B            DOTATION B            DOTACION B</i></p>
<p><b>Tavola N°7B - Rev. 0</b> __ <b>129690380</b>..... <b>12</b>  <i>GRUPPO CALIBRO            TESTER UNIT            KALIBERSATZ            GROUPE CALIBRE            GRUPO CALIBRE</i></p>	<p><b>Tavola N°15 - Rev. 0</b> __ <b>129791590</b>..... <b>22</b>  <i>CALIBRO LARGHEZZA PROFESSIONALE            PROFESSIONAL EXTERNAL DATA GAUGE            BERÜFLICHE BREITENLEHRE            CALIBRE LARGEUR PROFESSIONEL            CALIBRE ANCHO PROFESIONAL</i></p>
<p><b>Tavola N°8 - Rev. 0</b> __ <b>129690152</b>..... <b>13</b>  <i>GRUPPO AZIONAMENTO FRENO            BRAKE OPERATION GROUP            SATZ FÜR BREMSBETÄTIGUNG            GROUPE ACTIONNEMENT FREIN            GRUPO ACCIONAMIENTO FRENO</i></p>	<p><b>Tavola N°16 - Rev. 0</b> __ <b>129590710</b>..... <b>23</b>  <i>CALIBRO LARGHEZZA            WIDTH CALIPER            KALIBER FÜR BREITE            CALIBRE LARGEUR            CALIBRE ANCHO</i></p>





RAVAGLIOLI S.p.A.

**LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE  
LISTE DES PIECES DETACHEES - LISTA DE PIEZAS**

**Tavola N°1 - Rev. 0**

ASSIEME GENERALE  
MAIN ASSEMBLY  
GENERSATZ  
ASSEMBLAGE GENERAL  
JUNTO GENERAL


**Pag. 4 di 23**


G3.128R - GP3.128R


<b>Tav.</b>	<b>Cod.</b>	<b>Pos.</b>	<b>G3.128R</b>	<b>GP3.128R</b>				
2	129690073		•	•				
3A	129690090		•					
3B	129690030			•				
4	129690292		•	•				
5	129792570		•	•				
6	129792600		•	•				
7A	129690331		•					
7B	129690380			•				
8	129690152		•	•				
9A	129690610		•					
9B	129690590			•				
10	129793070		•	•				
11	129690341		•	•				
12	129390311			•				
13	129791580		•	•				
14A	-		•					
14B	-			•				
15	129791590		OPT	OPT				
16	129590710		OPT	OPT				


OPT = OPTIONAL







G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO MOTORE MOTOR UNIT MOTORSATZ GROUPE MOTEUR GRUPO MOTOR
	<b>Tavola N°2 - Rev. 0</b>	<b>129690073</b>	




G3.128R		GP3.128R			
•					
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>			GRUPPO ROTANTE COMPLETO COMPLETE ROTARY UNIT KOMPLETTER ROTIERENDER SATZ GROUPE ROTATIF COMPLET GRUPO GIRATORIO COMPLETO	<b>Pag. 6 di 23</b>
	<b>Tavola N°3A - Rev. 0</b>	<b>129690090</b>			





G3.128R		GP3.128R		
		•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO ROTANTE COMPLETO COMPLETE ROTARY UNIT KOMPLETTER ROTIERENDER SATZ GROUPE ROTATIF COMPLET GRUPO GIRATORIO COMPLETO	
	<b>Tavola N°3B - Rev. 0</b>		<b>129690030</b>	




G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO FRENO BRAKE UNIT BREMSATZ GRUPE FREIN GRUPO FRENO
	<b>Tavola N°4 - Rev. 0</b>	<b>129690292</b>	




G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO TELAIO FRAME UNIT RAHMENSATZ GROUPE CHASSIS GRUPO ESTRUCTURA
	<b>Tavola N°5 - Rev. 0</b>	<b>129792570</b>	<b>Pag. 9 di 23</b>



G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO PLANCIA BOARD UNIT BRETTSATZ GROUPE PLANCHE GRUPO TABLERO
	<b>Tavola N°6 - Rev. 0</b>	<b>129792600</b>	<b>Pag. 10 di 23</b>




G3.128R		GP3.128R		
•				
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO CALIBRO TESTER UNIT KALIBERSATZ GROUPE CALIBRE GRUPO CALIBRE	
	<b>Tavola N°7A - Rev. 0</b>		<b>129690331</b>	




G3.128R		GP3.128R		
		•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO CALIBRO TESTER UNIT KALIBERSATZ GROUPE CALIBRE GRUPO CALIBRE	
	<b>Tavola N°7B - Rev. 0</b>		<b>129690380</b>	







G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO AZIONAMENTO FRENO BRAKE OPERATION GROUP SATZ FÜR BREMSBETÄTIGUNG GROUPE ACTIONNEMENT FREIN GRUPO ACCIONAMIENTO FRENO
	<b>Tavola N°8 - Rev. 0</b>	<b>129690152</b>	




G3.128R	GP3.128R		
•			
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO PEDALE FRENO BRAKE PEDAL UNIT BREMSE PEDALSATZ GROUPE PÉDAL FREIN GRUPO PEDAL FRENO
	<b>Tavola N°9A - Rev. 0</b>	<b>129690610</b>	<b>Pag. 14 di 23</b>




G3.128R	GP3.128R		
	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO PEDALE FRENO BRAKE PEDAL UNIT BREMSE PEDALSATZ GROUPE PÉDAL FREIN GRUPO PEDAL FRENO
	<b>Tavola N°9B - Rev. 0</b>	<b>129690590</b>	




G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO ELETTRONICA ELECTRONICS UNIT ELEKTRONIKSATZ GROUPE ÉLECTRONIQUE GRUPO ELECTRÓNICA
	<b>Tavola N°10 - Rev. 0</b>	<b>129793070</b>	




G3.128R		GP3.128R			
•		•			
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>			GRUPPO IMPIANTO ELETTRICO ELECTRICAL SYSTEM UNIT SATZ VON ELEKTROANLAGE GROUPE INSTALLATION ÉLECTRIQUE GRUPO INSTALACIÓN ELÉCTRICA	<b>Pag. 17 di 23</b>
	<b>Tavola N°11 - Rev. 0</b>	<b>129690341</b>			




G3.128R		GP3.128R		
		•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		IMPIANTO SERRAGGIO PNEUMATICO PNEUMATIC TIGHTENING SYSTEM ANLAGE FÜR PNEUMATISCHE AUFSPANNUNG SYSTÈME SERRAGE PNEUMATIQUE SISTEMA APRIETE NEUMÁTICO	
	<b>Tavola N°12 - Rev. 0</b>	<b>129390311</b>		<b>Pag. 18 di 23</b>





G3.128R	GP3.128R		
•	•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		GRUPPO PROTEZIONE RUOTA WHEEL PROTECTION UNIT SATZ FÜR RADSCHUTZ GROUPE PROTECTION ROUE GRUPO PROTECCIÓN RUEDA
	<b>Tavola N°13 - Rev. 0</b>	<b>129791580</b>	




G3.128R	GP3.128R		
•			
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		DOTAZIONE A A EQUIPMENT AUSSTATTUNG A DOTACION A
	<b>Tavola N°14A - Rev. 0</b>		






G3.128R		GP3.128R		
		•		
 RAVAGLIOLI S.p.A.	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>			DOTAZIONE B B EQUIPMENT AUSSTATTUNG B DOTACION B
	<b>Tavola N°14B - Rev. 0</b>			



<b>G3.128R</b>	<b>GP3.128R</b>		
<b>OPT</b>	<b>OPT</b>		
 <b>RAVAGLIOLI S.p.A.</b>	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		<b>Pag. 22 di 23</b>
	<b>Tavola N°15 - Rev. 0</b>	<b>129791590</b>	



<b>G3.128R</b>	<b>GP3.128R</b>		
<b>OPT</b>	<b>OPT</b>		
 <b>RAVAGLIOLI S.p.A.</b>	<b>LISTA DEI COMPONENTI - LIST OF COMPONENTS - TEILELISTE</b> <b>LISTE DES PIÈCES DÉTACHÉES - LISTA DE PIEZAS</b>		<b>Pag. 23 di 23</b>
	<b>Tavola N°16 - Rev. 0</b>	<b>129590710</b>	