



## Lista tappi per spurgafreni / Adapters for brakebleeder



### Tappo nr. / Adapter nr.

Auto / Cars Diam. Filet.	1	2	3	4	5	6	8	10	11	12	13	19	22
	M28,2X3	M24,2X3	M29,5X3	M35,8X3	M45,8X3,5	M61,5X4	M44,6X3,5	M79,9X4	M67,1X4	M72,3X4	M46,7X3	M56,2X4	M30,1X2
ALFA				x			x						
AUDI					x								
AUSTIN	x				x								x
BMW				x									
CITROEN					x	x							
DAF	x				x								
DAEWOO					x								
FERRARI					x		x		x				
FIAT					x		x					x	
FORD					x						x		
INNOCENTI	x				x			x					x
JAGUAR					x								
LAMBORGHINI					x		x						
LADA							x						
LANCIA					x								
LAND-ROVER											x		
MASERATI					x			x	x				
MAZDA					x		x						
MERCEDES				x									
MITSUBISHI													
NISSAN											x		
OPEL					x								
PEUGEOT				x		x				x			
PORSCHE			x		x								
RENAULT					x	x			x	x			
ROVER	x				x								
SAAB					x								
SEAT					x								
SUZUKI					x								
TALBOT					x								
VOLKSWAGEN				x							x		
VOLVO				x				x					

## Lista tappi per spurgafreni / Adapters for brakebleeder



### Tappo nr. / Adapter nr.

Autocarri /Van Diam. Filet.	1	2	3	4	5	6	8	10	11	12	13	19	22
	M28,2X3	M24,2X3	M29,5X3	M35,8X3	M45,8X3,5	M61,5X4	M44,6X3,5	M79,9X4	M67,1X4	M72,3X4	M46,7X3	M56,2X4	M30,1X2
BEDFORD	x							x	x				
DAF					x								x
FIAT	x	x			x	x	x	x				x	
FORD					x								x
MERCEDES					x								
NISSAN													
O.M.	x	x			x	x	x						x
RENAULT					x	x							
SCANIA					x				x				
UNIC						x				x			