

POWERISE

Electromechanical drives

Spare part installation and removal instructions



1. Open trunk (see warning ⚠)
2. Remove rear shelf
3. Remove left rear wheel well liner inside trunk in order to remove upper D-column trim
4. Remove middle D-column trim from headliner



5. To remove left D-column trim, loosen safety dog first
⚠ Attention: Do not damage airbag unit, risk of injury!
6. Secure trunk lid against accidental lowering
7. Remove drive's rubber grommet from cable routing



8. Remove Powerise drive connector from plug connection and carefully guide out of cable routing



9. With a suitable tool, loosen safety clip from drive's ball pivot seat at the tailgate and remove
10. Repeat for drive's location on the body
11. Properly dispose of removed drive



Reverse sequence of instructions to install

12. Install drive (first body, then tailgate)
13. Guide connector through cable routing and connect
Important: Make sure it latches properly!
14. Insert rubber grommet
Important: Check that the installation is correct to ensure proper seal!
15. Attach safety clip for left D-column trim and reinstall D-column trim (left and top middle), check trunk weather stripping for proper fit
16. Install left rear wheel well liner inside trunk
17. Replace rear shelf
18. Initialize Powerise drive according to manufacturer's instructions Note: Connect charger to support battery; connect diagnostic device and enter key number or VIN; check fault memory entries and delete as applicable!



Brand: Chrysler
Model: Grand Cherokee
Typ: WK2
Model year: 01/2014 -

Original part number of drive:
68231347AA
68231347AB
68231347AC
Stabilus number:
841304
Installation location:
LH

Stabilus spare part number:
212017

Gas spring original part number:
68165052AC
Stabilus number:
781552
Installation location:
RH



Warning:

Risk of injury!
Prop tailgate in fully opened position.



Electromechanical drive is under spring pretension.