

Fitting Instructions - Read instructions carefully before fitting and follow them for correct use

IN8000 u

ULTI Rack








This FITTING INSTRUCTION is the property of VAN GUARD ACCESSORIES LTD. and must not be used for manufacturing purposes, copied nor communicated in any way to third parties without written permission from VAN GUARD ACCESSORIES LTD. IN8000 B - IW - 11/02/2016


Van Guard Accessories Ltd Fair Oak Close, Exeter Airport Business Park, Exeter, Devon, EX5 2UL www.van-guard.co.uk

VGUR-001

Vehicle:

Vauxhall Vivaro: 2002 - 2014 Renault Trafic: 2002 - 2014 Nissan Primastar: 2002 on Wheel Base: SWB (L1) Roof Height: Low (H1) Rear Doors: Twin







VGUR-002

Vehicle:

Vauxhall Vivaro: 2002 - 2014 Renault Trafic: 2002 - 2014 Nissan Primastar: 2002 on Wheel Base: SWB (L1) Roof Height: Low (H1) Rear Doors: Tailgate







VGUR-003

Vehicle:

Vauxhall Vivaro: 2002 - 2014 Renault Trafic: 2002 - 2014 Nissan Primastar: 2002 on Wheel Base: LWB (L2) Roof Height: Low (H1) Rear Doors: Twin








VGUR-004


Vehicle:


Vauxhall Vivaro: 2002 - 2014 Renault Trafic: 2002 - 2014 Nissan Primastar: 2002 on Wheel Base: LWB (L2) Roof Height: Low (H1) Rear Doors: Tailgate















































Place the remaining roof bars into position. See page 2 for the recommended distances between the roof bars. Once in position push on the lever to secure in place.





Secure the roller spigot to the **left hand roller bracket only** using a M8x20 hex bolt and a M8 shakeproof washer. Ensure that the shakeproof is on the inside of the roller bracket and that the spigot sits flush / straight. Tighten using the supplied tool.




IN8000 - PAGE 6 OF 7









Once fitted check fixings and parts to ensure they have been fully secured and tightened. Regularly check all fixings.



NOTES:

Maximum load capacity: 150KG (Including rack weight - please refer to page 2.) (Maximum load must be in accordance with the vehicle manufacturer's load bearing capacity. Please refer to the vehicles handbook.). Regularly check all fixings.

Retain these instructions for future reference.