

ADP-36FV

MXN

*ADAPTER FOR UNIVERSAL USE OF SHUTTER CAMERA

NOTE!

The shutter from the camera will open automatically when the yellow trigger wire from the ADP-36FV is activated by DC10~32V

