

Product Name: Craftsman 1200R

Product Number: 141200

Description

Work lamp & Bonnet lamp with 1200 lumens. Stepless dimming with 1200-80 lumens.
 Working time 2-15 hours pending on lumens.
 Fastening with both hooks and built in magnets.
 Rechargeable with USB C.

Specifications

Housing material	ABS TPU PC
Lens material	PC
On/off switch	yes
Battery type	Li-ion 3.7V/4000mAh
LED	10W COB
Colour temperature (Kelvin)	6400K
Colour rendering index (CRI)	>80
Output (lumens)	1200-80
Run time (hours) down to 10% of full lumens	2-15 pending on lumens
Beam distance	2.1M
Max charging input	5V1A
Charging time (hours)	5
Charging indicator	Yes
Battery level indicator	Yes
Charging port	TYPE C
Cable for charger, 1 m (supplied in box)	YES
Interchangeable battery	NO
Protection class	IP44
Operating temperature range (Celcius)	-10-40
Declaration of conformity	CE, UKCA
Battery MSDS	Yes
Additional info	



General Information

Lamp weight (g)	480
Lamp dimensions (cm)	520x44.6x37.5mm
EAN code box (1 pc)	57 03296 14120 8
EAN code inner carton =	N/A
EAN code outer carton =	57 03296 34240 7
Harmonized standard code	8513100000

Packaging

Description	Cardboard
Box dimensions (cm)	5.5*4.5*61.5
Box weight (g)	71,2
Carton quantity (pcs)	20
Carton size (cm)	25*66*25CM
Carton weight (kg)	12,5

Features

Flexible and rotatable ends with magnet.
 Hooks on backside. On/off and adjustable lumens via screw-button.

The following Safety Instructions apply
(Where relevant)

General Safety Instructions
 Do not shine in eyes. Do not immerse in water or other liquids. Do not cover the lens when turned on and do not place the product with the lens/light source direct on a surface. Do not operate if the housing, wiring compartment or lens is open, missing, or damaged. Allow the product to cool down sufficiently before cleaning. Do not use cleaners that contain abrasives or solvents. Use on flat, stable surfaces. Do not operate with wet hands. Do not disassemble. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative. Clean with a dry clean cloth. Please note that lighting products generate heat – if the heat exceeds 60 degrees turn off the product.

Safety Instructions - rechargeable products
 Always inspect the charging plug - it must look dry, clean and undamaged. Only use the supplied charging cable and/or charger. Do not use a modified or damaged charger. Do not try to charge the product if it looks damaged. Do not turn on when charging. Do not leave on charge for over 24 hours. Do not charge below 0°C, above 40°C or at high humidity. Do not leave the product on charge near flammable material as it can cause a fire. Never charge without supervision. Always pay extremely attention to Li-ion batteries as they can explode. If not handled properly, the battery may cause explosion, leakage or fire. Do not expose batteries to direct sunlight. Do not disassemble or modify batteries. Do not apply strong impacts to the battery. Do not get batteries wet. Keep batteries out of reach of children and animals. Do not place batteries on top of an electromagnetic field. Do not use batteries that work for an extremely short period of time. Do not short-circuit the battery. Do not put a battery in a microwave oven, pressure container, or other such devices. Do not recharge batteries where heat can build up. If not handled properly, the battery may cause explosion, leakage, or fire.

Safety Instructions – alkaline batteries
 Only use new and undamaged batteries. Remove batteries from a device that is not being used for an extended period as they can leak. Never try to charge a non-rechargeable battery.

